

Bolero, Phuntsho Automobile Workshop					
SI No	Description of Item	Unit of Measurement	Quantity	Period of Delivery (No. of Days)	Rate
1	Mahindra Bolero Spare parts, Air Filter	No	1	30	695
2	Mahindra Bolero Spare parts, Brake Shoe	Set	1	30	3995
3	Mahindra Bolero Spare parts, Brake Pad	Set	1	30	1395
4	Mahindra Bolero Spare parts, Hub Bearing F Inner	No	1	30	995
5	Mahindra Bolero Spare parts, Hub Bearing F Outer	No	1	30	895
6	Mahindra Bolero Spare parts, Hub Oil Seal	No	1	30	395
7	Mahindra Bolero Spare parts, Tube Oil Seal	No	1	30	95
8	Mahindra Bolero Spare parts, Brake Disc	No	1	30	2395
9	Mahindra Bolero Spare parts, Hub Check Nut	No	1	30	195
10	Mahindra Bolero Spare parts, Check Nut Lock	No	1	30	95
11	Mahindra Bolero Spare parts, Hub Splender	No	1	30	1295
12	Mahindra Bolero Spare parts, Shock Absorber Front	No	1	30	1795
13	Mahindra Bolero Spare parts, Shock Absorber Rear	No	1	30	1695
14	Mahindra Bolero Spare parts, Shock Absorber Bush	No	1	30	65.95
15	Mahindra Bolero Spare parts, Stablizer Bar Bush Front	No	1	30	155.95
16	Mahindra Bolero Spare parts, Stablizer Bar Bush Rear	No	1	30	95
17	Mahindra Bolero Spare parts, Link Bush Front	No	1	30	695
18	Mahindra Bolero Spare parts, Link Bush Rear	No	1	30	5.95
19	Mahindra Bolero Spare parts, Spring Main Rear	No	1	30	1795
24	Mahindra Bolero Spare parts, Spring Main Front	No	1	30	1095
29	Mahindra Bolero Spare parts, Spring Bush Small	No	1	30	135.95
30	Mahindra Bolero Spare parts, Spring Bush Big	No	1	30	145.95
31	Mahindra Bolero Spare parts, Spring Clamp	No	1	30	130.95

Labour Charge, Phuntsho Automobile workshop			
SI No	Description of Item (2)	Unit of Measurement (3)	Rate
1	Mahindra Bolero Spare parts, Air Filter changing	No	95
2	Mahindra Bolero Spare parts, Brake Shoe changing	Set	595
3	Mahindra Bolero Spare parts, Brake Pad changing	Set	395
4	Mahindra Bolero Spare parts, Hub Bearing F Inner changing	No	395
5	Mahindra Bolero Spare parts, Hub Bearing F Outer changing	No	395
6	Mahindra Bolero Spare parts, Hub Oil Seal changing	No	195
7	Mahindra Bolero Spare parts, Tube Oil Seal changing	No	95
8	Mahindra Bolero Spare parts, Brake Disc changing	No	395
9	Mahindra Bolero Spare parts, Hub Check Nut changing	No	95
10	Mahindra Bolero Spare parts, Check Nut Lock changing	No	95
11	Mahindra Bolero Spare parts, Hub Splender changing	No	95
12	Mahindra Bolero Spare parts, Shock Absorber Front changing	No	295
13	Mahindra Bolero Spare parts, Shock Absorber Rear changing	No	295
14	Mahindra Bolero Spare parts, Shock Absorber Bush changing	No	95
15	Mahindra Bolero Spare parts, Stablizer Bar Bush Front changing	No	195
16	Mahindra Bolero Spare parts, Stablizer Bar Bush Rear changing	No	95
17	Mahindra Bolero Spare parts, Link Bush Front changing	No	95
18	Mahindra Bolero Spare parts, Link Bush Rear changing	No	20.95
19	Mahindra Bolero Spare parts, Spring Main Rear changing	No	495
24	Mahindra Bolero Spare parts, Spring Main Front changing	No	395
29	Mahindra Bolero Spare parts, Spring Bush Small changing	No	195
30	Mahindra Bolero Spare parts, Spring Bush Big changing	No	195
31	Mahindra Bolero Spare parts, Spring Clamp changing	No	95

32	Mahindra Bolero Spare parts, Spring Bush Metal	No	1	30	295	32	Mahindra Bolero Spare parts, Spring Bush Metal changing	No	195
33	Mahindra Bolero Spare parts, Center Bolt	No	1	30	95	33	Mahindra Bolero Spare parts, Center Bolt changing	No	95
34	Mahindra Bolero Spare parts, Fuel Filter	No	1	30	295	34	Mahindra Bolero Spare parts, Fuel Filter changing	No	295
35	Mahindra Bolero Spare parts, Oil Filter	No	1	30	320.95	35	Mahindra Bolero Spare parts, Oil Filter changing	No	195
36	Mahindra Bolero Spare parts, Oil (Castrol)	Ltr	1	30	395	36	Mahindra Bolero Spare parts, Oil (Castrol) labor charge	Ltr	395
37	Mahindra Bolero Spare parts, Oil Mak	Ltr	1	30	395	37	Mahindra Bolero Spare parts, Oil Mak labor charge	Ltr	395
38	Mahindra Bolero Spare parts, Oil Rimula	Ltr	1	30	495	38	Mahindra Bolero Spare parts, Oil Rimula labor charge	Ltr	395
39	Mahindra Bolero Spare parts, Gear Oil Castrol	Ltr	1	30	495	39	Mahindra Bolero Spare parts, Gear Oil Castrol labor charge	Ltr	395
40	Mahindra Bolero Spare parts, Gear Oil Mak	Ltr	1	30	395	40	Mahindra Bolero Spare parts, Gear Oil Mak labor charge	Ltr	95
41	Mahindra Bolero Spare parts, Trasmission Oil	Ltr	1	30	395	41	Mahindra Bolero Spare parts, Trasmission Oil labor charge	Ltr	95
42	Mahindra Bolero Spare parts, Hyudraulic Oil	Ltr	1	30	95	42	Mahindra Bolero Spare parts, Hyudraulic Oil labor charge	Ltr	95
43	Mahindra Bolero Spare parts, Axle Bearing	No	1	30	1595	43	Mahindra Bolero Spare parts, Axle Bearing changing	No	495
44	Mahindra Bolero Spare parts, Axle Oil Seal Inner	No	1	30	495	44	Mahindra Bolero Spare parts, Axle Oil Seal Inner changing	No	195
45	Mahindra Bolero Spare parts, Axle Oil Seal Outer	No	1	30	395	45	Mahindra Bolero Spare parts, Axle Oil Seal Outer changing	No	195
46	Mahindra Bolero Spare parts, Axle Tube Oil Seal	No	1	30	95	46	Mahindra Bolero Spare parts, Axle Tube Oil Seal changing	No	95
47	Mahindra Bolero Spare parts, Rear Differential Assy	No	1	30	5995	47	Mahindra Bolero Spare parts, Rear Differential Assy changing changing	No	1395
48	Mahindra Bolero Spare parts, Differential Side Bearing	No	1	30	1495	48	Mahindra Bolero Spare parts, Differential Side Bearing changing	No	595
49	Mahindra Bolero Spare parts, Tail Inner Bearing	No	1	30	1395	49	Mahindra Bolero Spare parts, Tail Inner Bearing changing	No	695
50	Mahindra Bolero Spare parts, Tail Outer Bearing	No	1	30	1395	50	Mahindra Bolero Spare parts, Tail Outer Bearing changing	No	895
51	Mahindra Bolero Spare parts, Tail Oil Seal	No	1	30	995	51	Mahindra Bolero Spare parts, Tail Oil Seal changing	No	995
52	Mahindra Bolero Spare parts, Crown & Tail Assy	Set	1	30	4995	52	Mahindra Bolero Spare parts, Crown & Tail Assy changing	Set	1295
53	Mahindra Bolero Spare parts, Ball Joint Upper	No	1	30	1195	53	Mahindra Bolero Spare parts, Ball Joint Upper changing	No	395
54	Mahindra Bolero Spare parts, Ball Joint Lower	No	1	30	1095	54	Mahindra Bolero Spare parts, Ball Joint Lower changing	No	395
55	Mahindra Bolero Spare parts, Arm Lower	No	1	30	95	55	Mahindra Bolero Spare parts, Arm Lower changing	No	95
56	Mahindra Bolero Spare parts, Arm Upper	No	1	30	95	56	Mahindra Bolero Spare parts, Arm Upper changing	No	95

57	Mahindra Bolero Spare parts, Arm Bush Lower	No	1	30	95	57	Mahindra Bolero Spare parts, Arm Bush Lower changing	No	95
58	Mahindra Bolero Spare parts, Arm Bush Upper	No	1	30	95	58	Mahindra Bolero Spare parts, Arm Bush Upper changing	No	95
59	Mahindra Bolero Spare parts, Brake Hose Front	No	1	30	895	59	Mahindra Bolero Spare parts, Brake Hose Front changing	No	395
60	Mahindra Bolero Spare parts, Brake Hose Rear	No	1	30	795	60	Mahindra Bolero Spare parts, Brake Hose Rear changing	No	295
61	Mahindra Bolero Spare parts, Back Light	No	1	30	895	61	Mahindra Bolero Spare parts, Back Light changing	No	95
62	Mahindra Bolero Spare parts, Back Light Bulb	No	1	30	35.95	62	Mahindra Bolero Spare parts, Back Light Bulb changing	No	95
63	Mahindra Bolero Spare parts, Side Light	No	1	30	95	63	Mahindra Bolero Spare parts, Side Light changing	No	95
64	Mahindra Bolero Spare parts, Side Light Bulb	No	1	30	30.95	64	Mahindra Bolero Spare parts, Side Light Bulb changing	No	95
65	Mahindra Bolero Spare parts, Head Light	No	1	30	2995	65	Mahindra Bolero Spare parts, Head Light changing	No	195
66	Mahindra Bolero Spare parts, Head Light Bulb	No	1	30	295	66	Mahindra Bolero Spare parts, Head Light Bulb changing	No	195
67	Mahindra Bolero Spare parts, Head Gasket	No	1	30	2595	67	Mahindra Bolero Spare parts, Head Gasket changing	No	1995
68	Mahindra Bolero Spare parts, Head Gasket Set	Set	1	30	3995	68	Mahindra Bolero Spare parts, Head Gasket Set changing	Set	1995
69	Mahindra Bolero Spare parts, Water Pump	No	1	30	5195	69	Mahindra Bolero Spare parts, Water Pump changing	No	1295
70	Mahindra Bolero , Spare parts, Fan Belt	No	1	30	495	70	Mahindra Bolero , Spare parts, Fan Belt changing	No	395
71	Mahindra Bolero , Spare parts, Power Steering Belt	No	1	30	395	71	Mahindra Bolero , Spare parts, Power Steering Belt changing	No	295
72	Mahindra Bolero , Spare parts, Acc Belt	No	1	30	395	72	Mahindra Bolero , Spare parts, Acc Belt changing	No	195
73	Mahindra Bolero , Spare parts, Steering Damper	No	1	30	1595	73	Mahindra Bolero , Spare parts, Steering Damper changing	No	295
74	Mahindra Bolero , Spare parts, Steering Relay	No	1	30	95	74	Mahindra Bolero , Spare parts, Steering Relay changing	No	95
75	Mahindra Bolero , Spare parts, Steering Drop Arm	No	1	30	95	75	Mahindra Bolero , Spare parts, Steering Drop Arm changing	No	195
76	Mahindra Bolero , Spare parts, Steering Relay Kit	No	1	30	195	76	Mahindra Bolero , Spare parts, Steering Relay Kit changing	No	95
77	Mahindra Bolero , Spare parts, Brake Buckket Kit	No	1	30	95	77	Mahindra Bolero , Spare parts, Brake Buckket Kit changing	No	95
78	Mahindra Bolero , Spare parts, Wheel Cylinder Assy	No	1	30	1295	78	Mahindra Bolero , Spare parts, Wheel Cylinder Assy changing	No	295
79	Mahindra Bolero , Spare parts, Feed Pump	No	1	30	95	79	Mahindra Bolero , Spare parts, Feed Pump changing	No	195
80	Mahindra Bolero , Spare parts, Fuel Supply Pump	No	1	30	395	80	Mahindra Bolero , Spare parts, Fuel Supply Pump changing	No	595
81	Mahindra Bolero , Spare parts, Fuel Totter & Head	Set	1	30	95	81	Mahindra Bolero , Spare parts, Fuel Totter & Head changing	Set	95

82	Mahindra Bolero , Spare parts, Delivery Valve	Set	1	30	395	82	Mahindra Bolero , Spare parts, Delivery Valve changing	Set	95
83	Mahindra Bolero , Spare parts, Oil Supply Pump	Set	1	30	595	83	Mahindra Bolero , Spare parts, Oil Supply Pump changing	Set	295
84	Mahindra Bolero , Spare parts, Valve Oil Seal	Set	1	30	295	84	Mahindra Bolero , Spare parts, Valve Oil Seal changing	Set	395
85	Mahindra Bolero , Spare parts, Clutch Plate	Set	1	30	3295	85	Mahindra Bolero , Spare parts, Clutch Plate changing	Set	1795
86	Mahindra Bolero , Spare parts, Pressure Plate	No	1	30	4195	86	Mahindra Bolero , Spare parts, Pressure Plate changing	No	1595
87	Mahindra Bolero , Spare parts, Release Bearing	No	1	30	1195	87	Mahindra Bolero , Spare parts, Release Bearing changing	No	395
88	Mahindra Bolero , Spare parts, Master Cylinder Kit	No	1	30	95	88	Mahindra Bolero , Spare parts, Master Cylinder Kit changing	No	95
89	Mahindra Bolero , Spare parts, Master Cylinder	No	1	30	5995	89	Mahindra Bolero , Spare parts, Master Cylinder changing	No	995
90	Mahindra Bolero , Spare parts, Clutch Cylinder Upper	No	1	30	2295	90	Mahindra Bolero , Spare parts, Clutch Cylinder Upper changing	No	495
91	Mahindra Bolero , Spare parts, Clutch Cylinder Lower	No	1	30	1995	91	Mahindra Bolero , Spare parts, Clutch Cylinder Lower changing	No	395
92	Mahindra Bolero , Spare parts, Brake Booster	No	1	30	395	92	Mahindra Bolero , Spare parts, Brake Booster changing	No	95
93	Mahindra Bolero , Spare parts, Cross Bearing	No	1	30	895	93	Mahindra Bolero , Spare parts, Cross Bearing changing	No	395
94	Mahindra Bolero , Spare parts, Link	No	1	30	495	94	Mahindra Bolero , Spare parts, Link changing	No	195
95	Mahindra Bolero , Spare parts, C V Joint	No	1	30	95	95	Mahindra Bolero , Spare parts, C V Joint changing	No	295
96	Mahindra Bolero , Spare parts, Drive Shaft Assy	No	1	30	95	96	Mahindra Bolero , Spare parts, Drive Shaft Assy changing	No	95
97	Mahindra Bolero , Spare parts,Rear Spring Shackel	No	1	30	695	97	Mahindra Bolero , Spare parts,Rear Spring Shackel changing	No	195
98	Mahindra Bolero , Spare parts, Tie Rod End Small	No	1	30	595	98	Mahindra Bolero , Spare parts, Tie Rod End Small changing	No	295
99	Mahindra Bolero , Spare parts, Tie Rod End Big	No	1	30	695	99	Mahindra Bolero , Spare parts, Tie Rod End Big changing	No	195
100	Mahindra Bolero , Spare parts, Tie Rod End	Set	1	30	1295	100	Mahindra Bolero , Spare parts, Tie Rod End changing	Set	195
101	Mahindra Bolero , Spare parts, King Pin Bearing	Set	1	30	95	101	Mahindra Bolero , Spare parts, King Pin Bearing changing	Set	95
102	Mahindra Bolero , Spare parts, King Pin Kit	Set	1	30	95	102	Mahindra Bolero , Spare parts, King Pin Kit changing	Set	95
103	Mahindra Bolero , Spare parts, Radiator Cap	Set	1	30	295	103	Mahindra Bolero , Spare parts, Radiator Cap changing	Set	95
104	Mahindra Bolero , Spare parts, Wheel Nuts & Bolts	No	1	30	295	104	Mahindra Bolero , Spare parts, Wheel Nuts & Bolts changing	No	195
105	Mahindra Bolero , Spare parts, Self Armature	No	1	30	2595	105	Mahindra Bolero , Spare parts, Self Armature changing	No	1295
106	Mahindra Bolero Spare parts, Self Carbon	No	1	30	1495	106	Mahindra Bolero Spare parts, Self Carbon changing	No	895

107	Mahindra Bolero Spare parts, Self Carnon Rocker	No	1	30	12.95	107	Mahindra Bolero Spare parts, Self Carnon Rocker changing	No	795
108	Mahindra Bolero Spare parts, Self Plunger	No	1	30	6.95	108	Mahindra Bolero Spare parts, Self Plunger changing	No	195
109	Mahindra Bolero Spare parts, Timing Belt	No	1	30	95	109	Mahindra Bolero Spare parts, Timing Belt changing	No	95
110	Mahindra Bolero Spare parts, Glow Plug	No	1	30	95	110	Mahindra Bolero Spare parts, Glow Plug changing	No	495
111	Mahindra Bolero Spare parts, Engine Mounting	No	1	30	95	111	Mahindra Bolero Spare parts, Engine Mounting changing	No	95
112	Mahindra Bolero Spare parts, Gear Box Mounting	No	1	30	95	112	Mahindra Bolero Spare parts, Gear Box Mounting changing	No	95
113	Mahindra Bolero Spare parts, Wiper Blade	No	1	30	395	113	Mahindra Bolero Spare parts, Wiper Blade changing	No	50.95
114	Mahindra Bolero Spare parts, Battery	No	1	30	8995	114	Mahindra Bolero Spare parts, Battery changing	No	95
115	Mahindra Bolero Spare parts, Brake Oil	Ltr	1	30	295	115	Mahindra Bolero Spare parts, Brake Oil changing	Ltr	195
116	Mahindra Bolero Spare parts, Power Steering Oil	Ltr	1	30	295	116	Mahindra Bolero Spare parts, Power Steering Oil changing	Ltr	195
117	Mahindra Bolero Spare parts, Key Lock Set	Set	1	30	2995	117	Mahindra Bolero Spare parts, Key Lock Set changing	Set	95
118	Mahindra Bolero Spare parts, Parking Cable Rear	No	1	30	895	118	Mahindra Bolero Spare parts, Parking Cable Rear changing	No	595
119	Mahindra Bolero Spare parts, Parking Cable Front	No	1	30	595	119	Mahindra Bolero Spare parts, Parking Cable Front changing	No	395
120	Mahindra Bolero Spare parts, Accelator Cable	No	1	30	495	120	Mahindra Bolero Spare parts, Accelator Cable changing	No	295
121	Mahindra Bolero Spare parts, Km Cable	No	1	30	695	121	Mahindra Bolero Spare parts, Km Cable changing	No	295
122	Mahindra Bolero Spare parts, Rear Axle Corn	No	1	30	95	122	Mahindra Bolero Spare parts, Rear Axle Corn changing	No	195
123	Mahindra Bolero Spare parts, Spring Pad	No	1	30	95	123	Mahindra Bolero Spare parts, Spring Pad changing	No	95
124	Mahindra Bolero Spare parts, Piston	Set	1	30	2995	124	Mahindra Bolero Spare parts, Piston changing	Set	1995
125	Mahindra Bolero Spare parts, Piston Ring	Set	1	30	3995	125	Mahindra Bolero Spare parts, Piston Ring changing	Set	1995
126	Mahindra Bolero Spare parts, Linner	Set	1	30	3995	126	Mahindra Bolero Spare parts, Linner changing	Set	1995
127	Mahindra Bolero Spare parts, Intake Valve	Set	1	30	595	127	Mahindra Bolero Spare parts, Intake Valve changing	Set	895
128	Mahindra Bolero Spare parts, Exhuast Valve	Set	1	30	695	128	Mahindra Bolero Spare parts, Exhuast Valve changing	Set	595
129	Mahindra Bolero Spare parts, Vale Guide	Set	1	30	395	129	Mahindra Bolero Spare parts, Vale Guide changing	Set	495
130	Mahindra Bolero Spare parts, Vaive Seat	Set	1	30	495	130	Mahindra Bolero Spare parts, Vaive Seat changing	Set	695
131	Mahindra Bolero Spare parts, Connecting Bearing	Set	1	30	1895	131	Mahindra Bolero Spare parts, Connecting Bearing changing	Set	1295

132	Mahindra Bolero Spare parts, Main Bearing	Set	1	30	1495		132	Mahindra Bolero Spare parts, Main Bearing changing	Set	1595
133	Mahindra Bolero Spare parts, Cam Shaft Bearing	Set	1	30	1295		133	Mahindra Bolero Spare parts, Cam Shaft Bearing changing	Set	1295
134	Mahindra Bolero Spare parts, Thrush Washer	Set	1	30	395		134	Mahindra Bolero Spare parts, Thrush Washer changing	Set	295
135	Mahindra Bolero Spare parts, Crank Shaft	No	1	30	2995		135	Mahindra Bolero Spare parts, Crank Shaft changing	No	1395
136	Mahindra Bolero Spare parts, Connecting Rod	No	1	30	995		136	Mahindra Bolero Spare parts, Connecting Rod changing	No	895
137	Mahindra Bolero Spare parts, Valve Set	Set	1	30	495		137	Mahindra Bolero Spare parts, Valve Set changing	Set	395
138	Mahindra Bolero Spare parts, Grease	Kg	1	30	695		138	Mahindra Bolero Spare parts, Grease changing	Kg	20.95
139	Mahindra Bolero Spare parts, Dhoti	Kg	1	30	35.95		140	Mahindra Bolero Spare parts, Sk Oil changing	Ltr	0
140	Mahindra Bolero Spare parts, Sk Oil	Ltr	1	30	130.95		141	Mahindra Bolero Spare parts, Water Paper changing	No	0
141	Mahindra Bolero Spare parts, Water Paper	No	1	30	50.95		142	Mahindra Bolero Spare parts, 4W Yok And Teeth changing	Set	1495
142	Mahindra Bolero Spare parts, 4W Yok And Teeth	Set	1	30	2995		143	Mahindra Bolero Spare parts, 2W Yok And Teeth changing	Set	595
143	Mahindra Bolero Spare parts, 2W Yok And Teeth	Set	1	30	95		144	Mahindra Bolero Spare parts, Main Bearing Oil Seal changing	No	995
144	Mahindra Bolero Spare parts, Main Bearing Oil Seal	No	1	30	995		145	Mahindra Bolero Spare parts, U-Bolt changing	No	295
145	Mahindra Bolero Spare parts, U-Bolt	No	1	30	395		146	Mahindra Bolero Spare parts, Mobil Filter changing	No	195
146	Mahindra Bolero Spare parts, Mobil Filter	No	1	30	320.95		147	Mahindra Bolero Spare parts, Diesel Filter changing	No	295
147	Mahindra Bolero Spare parts, Diesel Filter	No	1	30	295		148	Mahindra Bolero Spare parts, CV Joint Assembly changing	No	95
148	Mahindra Bolero Spare parts, CV Joint Assembly	No	1	30	95		149	Mahindra Bolero Spare parts, Dust Guard changing	Set	195
149	Mahindra Bolero Spare parts, Dust Guard	Set	1	30	295		150	Mahindra Bolero Spare parts, Engine Oil changing	Ltr	395
150	Mahindra Bolero Spare parts, Engine Oil	Ltr	1	30	395		151	Mahindra Bolero Spare parts, Coolant changing	Ltr	395
151	Mahindra Bolero Spare parts, Coolant	Ltr	1	30	395		152	Mahindra Bolero Spare parts, Distilled Water changing	Ltr	50.95
152	Mahindra Bolero Spare parts, Distilled Water	Ltr	1	30	50.95		153	Mahindra Bolero Spare parts, Bonnet Cable changing	Set	295
153	Mahindra Bolero Spare parts, Bonnet Cable	Set	1	30	695		154	Mahindra Bolero Spare parts, Hand Brake Cable changing	Set	395
154	Mahindra Bolero Spare parts, Hand Brake Cable	Set	1	30	0		155	Mahindra Bolero Spare parts, Door Rubber changing	Set	295
155	Mahindra Bolero Spare parts, Door Rubber	Set	1	30	0		156	Mahindra Bolero Spare parts, Safe Guard changing	Set	195
156	Mahindra Bolero Spare parts, Safe Guard	Set	1	30	795		157	Mahindra Bolero Spare parts, Fog Light changing	Set	695

157	Mahindra Bolero Spare parts, Fog Light	Set	1	30	95		158	Mahindra Bolero Spare parts, Horn changing	No	395
158	Mahindra Bolero Spare parts, Horn	No	1	30	1595		159	Mahindra Bolero Spare parts, Pop.Shaft-Yoke & Teeth changing	No	595
159	Mahindra Bolero Spare parts, Pop.Shaft-Yoke & Teeth	No	1	30	995		160	Mahindra Bolero Spare parts, Fuse changing	No	20.95
160	Mahindra Bolero Spare parts, Fuse	No	1	30	20.95		161	Mahindra Bolero Spare parts, Wheel Bearing changing	No	395
161	Mahindra Bolero Spare parts, Wheel Bearing	No	1	30	995		161	Mahindra Bolero Spare parts, Wheel Bearing	No	395