

Bolero DC turbo, Phuntsho Automobile Workshop					
SI no	Description of Item	Unit of Measure ment	Quantity	Period of Delivery (No. of Days)	Rate
1	Mahindra Bolero DC turbo Spare parts, Air Filter	No	1	30	695
2	Mahindra Bolero DC turbo Spare parts, Brake Shoe	Set	1	30	1995
3	Mahindra Bolero DC Turbo Spare Parts, Brake shoe Assy rear	No	1	30	1395
4	Mahindra Bolero Dc Turbo Spare parts, Brake shoe Rear STD	No	1	30	295
5	Mahindra Bolero DC turbo Spare parts, Brake Pad	Set	1	30	1395
6	Mahindra Bolero DC turbo Spare parts, Hub Bearing F Inner	No	1	30	1395
7	Mahindra Bolero DC turbo Spare parts, Hub Bearing F Outer	No	1	30	995
8	Mahindra Bolero DC turbo Spare parts, Hub Oil Seal	No	1	30	495
9	Mahindra Bolero DC turbo Spare parts, Tube Oil Seal	No	1	30	9.95
10	Mahindra Bolero DC turbo Spare parts, Brake Disc	No	1	30	2395
11	Mahindra Bolero DC turbo Spare parts, Hub Check Nut	No	1	30	195
12	Mahindra Bolero DC turbo Spare parts, Check Nut Lock	No	1	30	130.95
13	Mahindra Bolero DC turbo Spare parts, Hub Splender	No	1	30	1295
14	Mahindra Bolero DC turbo Spare parts, Shock Absorber Front	No	1	30	1795
15	Mahindra Bolero DC turbo Spare parts, Shock Absorber Rear	No	1	30	1695

Labour Charge, Phuntsho Automobile workshop			
SI no	Description of Item	Unit of Measure ment	Rate
1	Mahindra Bolero DC turbo Spare parts, Air Filter changing	No	95
2	Mahindra Bolero DC turbo Spare parts, Brake Shoe changing	Set	595
3	Mahindra Bolero DC Turbo Spare Parts, Brake shoe Assy rear changing	No	595
4	Mahindra Bolero Dc Turbo Spare parts, Brake shoe Rear STD changing	No	595
5	Mahindra Bolero DC turbo Spare parts, Brake Pad changing	Set	395
6	Mahindra Bolero DC turbo Spare parts, Hub Bearing F Inner changing	No	395
7	Mahindra Bolero DC turbo Spare parts, Hub Bearing F Outer changing	No	295
8	Mahindra Bolero DC turbo Spare parts, Hub Oil Seal changing	No	195
9	Mahindra Bolero DC turbo Spare parts, Tube Oil Seal changing	No	95
10	Mahindra Bolero DC turbo Spare parts, Brake Disc changing	No	95
11	Mahindra Bolero DC turbo Spare parts, Hub Check Nut changing	No	95
12	Mahindra Bolero DC turbo Spare parts, Check Nut Lock changing	No	95
13	Mahindra Bolero DC turbo Spare parts, Hub Splender changing	No	295
14	Mahindra Bolero DC turbo Spare parts, Shock Absorber Front changing	No	295
15	Mahindra Bolero DC turbo Spare parts, Shock Absorber Rear changing	No	295

16	Mahindra Bolero DC turbo Spare parts, Shock Absorber Bush	No	1	30	65.95		16	Mahindra Bolero DC turbo Spare parts, Shock Absorber Bush changing	No	95
17	Mahindra Bolero DC turbo Spare parts, Stablizer Bar Bush Front	No	1	30	155.95		17	Mahindra Bolero DC turbo Spare parts, Stablizer Bar Bush Front changing	No	195
18	Mahindra Bolero DC turbo Spare parts, Stablizer Bar Bush Rear	No	1	30	95		18	Mahindra Bolero DC turbo Spare parts, Stablizer Bar Bush Rear changing	No	95
19	Mahindra Bolero DC turbo Spare parts, Link Bush Front	No	1	30	995		19	Mahindra Bolero DC turbo Spare parts, Link Bush Front changing	No	95
20	Mahindra Bolero DC turbo Spare partss, Link Bush Rear	No	1	30	5.95		20	Mahindra Bolero DC turbo Spare partss, Link Bush Rear changing	No	20.95
21	Mahindra Bolero DC turbo Spare parts, Spring Main Rear	No	1	30	1795		21	Mahindra Bolero DC turbo Spare parts, Spring Main Rear changing	No	495
22	Mahindra Bolero DC turbo Spare parts, Spring Main Front	No	1	30	95		22	Mahindra Bolero DC turbo Spare parts, Spring Main Front changing	No	95
23	Mahindra Bolero DC turbo Spare parts, Spring Bush Small	No	1	30	135.95		23	Mahindra Bolero DC turbo Spare parts, Spring Bush Small	No	195
24	Mahindra Bolero DC turbo Spare parts, Spring Bush Big	No	1	30	145.95		24	Mahindra Bolero DC turbo Spare parts, Spring Bush Big changing	No	195
25	Mahindra Bolero DC turbo Spare parts, Spring Clamp	No	1	30	130.95		25	Mahindra Bolero DC turbo Spare parts, Spring Clamp changing	No	95
26	Mahindra Bolero DC turbo Spare parts, Spring Bush Metal	No	1	30	295		26	Mahindra Bolero DC turbo Spare parts, Spring Bush Metal changing	No	195
27	Mahindra Bolero DC turbo Spare parts, Center Bolt	No	1	30	95		27	Mahindra Bolero DC turbo Spare parts, Center Bolt changing	No	95
28	Mahindra Bolero DC turbo Spare parts, Fuel Filter	No	1	30	295		28	Mahindra Bolero DC turbo Spare parts, Fuel Filter changing	No	295
29	Mahindra Bolero DC turbo Spare parts, Oil Filter	No	1	30	320.95		29	Mahindra Bolero DC turbo Spare parts, Oil Filter changing	No	195
30	Mahindra Bolero DC turbo Spare parts, Oil (Castrol)	Ltr	1	30	395		30	Mahindra Bolero DC turbo Spare parts, Oil (Castrol) changing	Ltr	395
31	Mahindra Bolero DC turbo Spare parts, Oil Mak	Ltr	1	30	395		31	Mahindra Bolero DC turbo Spare parts, Oil Mak changing	Ltr	395
32	Mahindra Bolero DC turbo Spare parts, Oil Rimula	Ltr	1	30	495		32	Mahindra Bolero DC turbo Spare parts, Oil Rimula changing	Ltr	395
33	Mahindra Bolero DC turbo Spare parts, Gear Oil Castrol	Ltr	1	30	495		33	Mahindra Bolero DC turbo Spare parts, Gear Oil Castrol changing	Ltr	395
34	Mahindra Bolero DC turbo Spare parts, Gear Oil Mak	Ltr	1	30	395		34	Mahindra Bolero DC turbo Spare parts, Gear Oil Mak changing	Ltr	95

35	Mahindra Bolero DC turbo Spare parts, Trasmission Oil	Ltr	1	30	395		35	Mahindra Bolero DC turbo Spare parts, Trasmission Oil changing	Ltr	95
36	Mahindra Bolero DC turbo Spare parts, Hyudraulic Oil	Ltr	1	30	95		36	Mahindra Bolero DC turbo Spare parts, Hyudraulic Oil changing	Ltr	95
37	Mahindra Bolero DC turbo Spare parts, Axle Bearing	No	1	30	1595		37	Mahindra Bolero DC turbo Spare parts, Axle Bearing changing	No	495
38	Mahindra Bolero DC turbo Spare parts, Axle Oil Seal Inner	No	1	30	495		38	Mahindra Bolero DC turbo Spare parts, Axle Oil Seal Inner	No	295
39	Mahindra Bolero DC turbo Spare parts, Axle Oil Seal Outer	No	1	30	395		39	Mahindra Bolero DC turbo Spare parts, Axle Oil Seal Outer changing	No	195
40	Mahindra Bolero DC turbo Spare parts,Mahindra Bolero Spare parts, Axle Tube Oil Seal	No	1	30	95		40	Mahindra Bolero DC turbo Spare parts, Mahindra Bolero Spare parts, Axle Tube Oil Seal changing	No	95
41	Mahindra Bolero DC turbo Spare parts,Rear Differential Assy	No	1	30	5995		41	Mahindra Bolero DC turbo Spare parts, Rear Differential Assy changing	No	1395
42	Mahindra Bolero DC turbo Spare parts, Differential Side Bearing	No	1	30	1495		42	Mahindra Bolero DC turbo Spare parts, Differential Side Bearing changing	No	595
43	Mahindra Bolero DC turbo Spare parts, Tail Inner Bearing	No	1	30	1395		43	Mahindra Bolero DC turbo Spare parts, Tail Inner Bearing changing	No	695
44	Mahindra Bolero DC turbo Spare parts, Tail Outer Bearing	No	1	30	1395		44	Mahindra Bolero DC turbo Spare parts, Tail Outer Bearing changing	No	895
45	Mahindra Bolero DC turbo Spare parts, Tail Oil Seal	No	1	30	995		45	Mahindra Bolero DC turbo Spare parts, Tail Oil Seal changing	No	995
46	Mahindra Bolero DC turbo Spare parts, Crown & Tail Assy	Set	1	30	4995		46	Mahindra Bolero DC turbo Spare parts, Crown & Tail Assy changing	Set	1295
47	Mahindra Bolero DC turbo Spare parts,Ball Joint Upper	No	1	30	1195		47	Mahindra Bolero DC turbo Spare parts, Ball Joint Upper changing	No	395
48	Mahindra Bolero DC turbo Spare parts, Ball Joint Lower	No	1	30	1095		48	Mahindra Bolero DC turbo Spare parts, Ball Joint Lower changing	No	395
49	Mahindra Bolero DC turbo Spare parts, Arm Lower	No	1	30	1295		49	Mahindra Bolero DC turbo Spare parts, Arm Lower changing	No	95
50	Mahindra Bolero DC turbo Spare parts, Arm Upper	No	1	30	1195		50	Mahindra Bolero DC turbo Spare parts, Arm Upper changing	No	95
51	Mahindra Bolero DC turbo Spare parts, Arm Bush Lower	No	1	30	595		51	Mahindra Bolero DC turbo Spare parts, Arm Bush Lower changing	No	95

52	Mahindra Bolero DC turbo Spare parts, Arm Bush Upper	No	1	30	395		52	Mahindra Bolero DC turbo Spare parts, Arm Bush Upper changing	No	95
53	Mahindra Bolero DC turbo Spare parts, Brake Hose Front	No	1	30	895		53	Mahindra Bolero DC turbo Spare parts, Brake Hose Front changing	No	395
54	Mahindra Bolero DC turbo Spare parts, Brake Hose Rear	No	1	30	795		54	Mahindra Bolero DC turbo Spare parts, Brake Hose Rear changing	No	295
55	Mahindra Bolero DC turbo Spare parts, Back Light	No	1	30	895		55	Mahindra Bolero DC turbo Spare parts, Back Light changing	No	95
56	Mahindra Bolero DC turbo Spare parts, Back Light Bulb	No	1	30	35.95		56	Mahindra Bolero DC turbo Spare parts, Back Light Bulb changing	No	95
57	Mahindra Bolero DC turbo Spare parts, Side Light	No	1	30	95		57	Mahindra Bolero DC turbo Spare parts, Side Light changing	No	95
58	Mahindra Bolero DC turbo Spare parts, Side Light Bulb	No	1	30	30.95		58	Mahindra Bolero DC turbo Spare parts, Side Light Bulb changing	No	95
59	Mahindra Bolero DC turbo Spare parts, Head Light	No	1	30	1595		59	Mahindra Bolero DC turbo Spare parts, Head Light changing	No	195
60	Mahindra Bolero DC turbo Spare parts, Head Light Bulb, (12v 60/55w)	No	1	30	295		60	Mahindra Bolero DC turbo Spare parts, Head Light Bulb, (12v 60/55w) changing	No	195
61	Mahindra Bolero DC turbo Spare parts, Head Gasket	No	1	30	2595		61	Mahindra Bolero DC turbo Spare parts, Head Gasket	No	1995
62	Mahindra Bolero DC turbo Spare parts, Head Gasket Set	Set	1	30	3995		62	Mahindra Bolero DC turbo Spare parts, Head Gasket Set changing	Set	1995
63	Mahindra Bolero DC turbo Spare parts, Water Pump	No	1	30	6995		63	Mahindra Bolero DC turbo Spare parts, Water Pump changing	No	1295
64	Mahindra Bolero DC turbo Spare parts, Fan Belt	No	1	30	1595		64	Mahindra Bolero DC turbo Spare parts, Fan Belt changing	No	395
65	Mahindra Bolero DC turbo Spare parts, Power Steering Belt	No	1	30	395		65	Mahindra Bolero DC turbo Spare parts, Power Steering Belt changing	No	295
66	Mahindra Bolero DC turbo Spare parts, Acc Belt	No	1	30	395		66	Mahindra Bolero DC turbo Spare parts, Acc Belt changing	No	195
67	Mahindra Bolero DC turbo Spare parts, Steering Damper	No	1	30	1595		67	Mahindra Bolero DC turbo Spare parts, Steering Damper changing	No	295
68	Mahindra Bolero DC turbo Spare parts, Steering Relay	No	1	30	95		68	Mahindra Bolero DC turbo Spare parts, Steering Relay changing	No	95
69	Mahindra Bolero DC turbo Spare parts, Steering Drop Arm	No	1	30	95		69	Mahindra Bolero DC turbo Spare parts, Steering Drop Arm changing	No	195
70	Mahindra Bolero DC turbo Spare parts, Steering Relay Kit	No	1	30	195		70	Mahindra Bolero DC turbo Spare parts, Steering Relay Kit changing	No	95

71	Mahindra Bolero DC turbo Spare parts, Brake Buckket Kit	No	1	30	95		71	Mahindra Bolero DC turbo Spare parts, Brake Buckket Kit changing	No	95
72	Mahindra Bolero DC turbo Spare parts, Wheel Cylinder Assy	No	1	30	1295		72	Mahindra Bolero DC turbo Spare parts, Wheel Cylinder Assy changing	No	295
73	Mahindra Bolero DC turbo Spare parts, Feed Pump	No	1	30	95		73	Mahindra Bolero DC turbo Spare parts, Feed Pump changing	No	195
74	Mahindra Bolero DC turbo Spare parts, Fuel Supply Pump	No	1	30	395		74	Mahindra Bolero DC turbo Spare parts, Fuel Supply Pump changing	No	595
75	Mahindra Bolero DC turbo Spare parts, Fuel Totter & Head	Set	1	30	95		75	Mahindra Bolero DC turbo Spare parts, Fuel Totter & Head changing	Set	95
76	Mahindra Bolero DC turbo Spare parts, Delivery Valve	Set	1	30	395		76	Mahindra Bolero DC turbo Spare parts, Delivery Valve changing	Set	95
77	Mahindra Bolero DC turbo Spare parts, Oil Supply Pump	Set	1	30	595		77	Mahindra Bolero DC turbo Spare parts, Oil Supply Pump changing	Set	295
78	Mahindra Bolero DC turbo Spare parts, Valve Oil Seal	Set	1	30	295		78	Mahindra Bolero DC turbo Spare parts, Valve Oil Seal changing	Set	395
79	Mahindra Bolero DC turbo Spare parts, Clutch Plate	Set	1	30	3995		79	Mahindra Bolero DC turbo Spare parts, Clutch Plate changing	Set	1795
80	Mahindra Bolero DC turbo Spare parts, Pressure Plate	No	1	30	4995		80	Mahindra Bolero DC turbo Spare parts, Pressure Plate changing	No	1595
81	Mahindra Bolero DC turbo Spare parts, Release Bearing	No	1	30	1195		81	Mahindra Bolero DC turbo Spare parts, Release Bearing changing	No	395
82	Mahindra Bolero DC turbo Spare parts, Master Cylinder Kit	No	1	30	95		82	Mahindra Bolero DC turbo Spare parts, Master Cylinder Kit	No	95
83	Mahindra Bolero DC turbo Spare parts, Master Cylinder	No	1	30	5995		83	Mahindra Bolero DC turbo Spare parts, Master Cylinder	No	995
84	Mahindra Bolero DC turbo Spare parts, Clutch Cylinder Upper	No	1	30	2295		84	Mahindra Bolero DC turbo Spare parts, Clutch Cylinder Upper changing	No	495
85	Mahindra Bolero DC turbo Spare parts, Clutch Cylinder Lower	No	1	30	1995		85	Mahindra Bolero DC turbo Spare parts, Clutch Cylinder Lower changing	No	395
86	Mahindra Bolero DC turbo Spare parts, Brake Booster	No	1	30	395		86	Mahindra Bolero DC turbo Spare parts, Brake Booster changing	No	95
87	Mahindra Bolero DC turbo Spare parts, Cross Bearing	No	1	30	895		87	Mahindra Bolero DC turbo Spare parts, Cross Bearing changing	No	395
88	Mahindra Bolero DC turbo Spare parts, Link	No	1	30	895		88	Mahindra Bolero DC turbo Spare parts, Link changing	No	195

89	Mahindra Bolero DC turbo Spare parts, C V Joint	No	1	30	1995		89	Mahindra Bolero DC turbo Spare parts, C V Joint changing	No	295
90	Mahindra Bolero DC turbo Spare parts, Drive Shaft Assy	No	1	30	95		90	Mahindra Bolero DC turbo Spare parts, Drive Shaft Assy changing	No	95
91	Mahindra Bolero DC turbo Spare parts,Rear Spring Shackel	No	1	30	695		91	Mahindra Bolero DC turbo Spare parts, Rear Spring Shackel changing	No	195
92	Mahindra Bolero DC turbo Spare parts, Tie Rod End Small	No	1	30	595		92	Mahindra Bolero DC turbo Spare parts, Tie Rod End Small changing	No	295
93	Mahindra Bolero DC turbo Spare parts, Tie Rod End Big	No	1	30	695		93	Mahindra Bolero DC turbo Spare parts, Tie Rod End Big changing	No	195
94	Mahindra Bolero DC turbo Spare parts, Tie Rod End	Set	1	30	1295		94	Mahindra Bolero DC turbo Spare parts, Tie Rod End changing	Set	195
95	Mahindra Bolero DC turbo Spare parts, King Pin Bearing	Set	1	30	95		95	Mahindra Bolero DC turbo Spare parts, King Pin Bearing changing	Set	95
96	Mahindra Bolero DC turbo Spare parts, King Pin Kit	Set	1	30	95		96	Mahindra Bolero DC turbo Spare parts, King Pin Kit changing	Set	95
97	Mahindra Bolero DC turbo Spare parts, Radiator Cap	Set	1	30	295		97	Mahindra Bolero DC turbo Spare parts, Radiator Cap changing	Set	95
98	Mahindra Bolero DC turbo Spare parts, Wheel Nuts & Bolts	No	1	30	295		98	Mahindra Bolero DC turbo Spare parts, Wheel Nuts & Bolts changing	No	195
99	Mahindra Bolero DC turbo Spare parts, Self Armature	No	1	30	2595		99	Mahindra Bolero DC turbo Spare parts, Self Armature changing	No	1295
100	Mahindra Bolero DC turbo Spare parts, Self Carbon	No	1	30	1495		100	Mahindra Bolero DC turbo Spare parts, Self Carbon changing	No	895
101	Mahindra Bolero DC turbo Spare parts, Self Carnon Rocker	No	1	30	12.95		101	Mahindra Bolero DC turbo Spare parts, Self Carnon Rocker changing	No	795
102	Mahindra Bolero DC turbo Spare parts, Self Plunger	No	1	30	6.95		102	Mahindra Bolero DC turbo Spare parts, Self Plunger changing	No	195
103	Mahindra Bolero DC turbo Spare parts, Timing Belt	No	1	30	95		103	Mahindra Bolero DC turbo Spare parts, Timing Belt changing	No	95
104	Mahindra Bolero DC turbo Spare parts, Glow Plug	No	1	30	1995		104	Mahindra Bolero DC turbo Spare parts, Glow Plug changing	No	495
105	Mahindra Bolero DC turbo Spare parts, Engine Mounting	No	1	30	95		105	Mahindra Bolero DC turbo Spare parts, Engine Mounting changing	No	95
106	Mahindra Bolero DC turbo Spare parts, Gear Box Mounting	No	1	30	95		106	Mahindra Bolero DC turbo Spare parts, Gear Box Mounting changing	No	95

107	Mahindra Bolero DC turbo Spare parts, Wiper Blade	No	1	30	395		107	Mahindra Bolero DC turbo Spare parts, Wiper Blade changing	No	50.95
108	Mahindra Bolero DC turbo Spare parts, Battery	No	1	30	8995		108	Mahindra Bolero DC turbo Spare parts, Battery changing	No	95
109	Mahindra Bolero DC turbo Spare parts, Brake Oil	Ltr	1	30	295		109	Mahindra Bolero DC turbo Spare parts, Brake Oil changing	Ltr	195
110	Mahindra Bolero DC turbo Spare parts, Power Steering Oil	Ltr	1	30	295		110	Mahindra Bolero DC turbo Spare parts, Power Steering Oil changing	Ltr	195
111	Mahindra Bolero DC turbo Spare parts, Key Lock Set	Set	1	30	2995		111	Mahindra Bolero DC turbo Spare parts, Key Lock Set changing	Set	95
112	Mahindra Bolero DC turbo Spare parts, Parking Cable Rear	No	1	30	895		112	Mahindra Bolero DC turbo Spare parts, Parking Cable Rear changing	No	595
113	Mahindra Bolero DC turbo Spare parts, Parking Cable Front	No	1	30	595		113	Mahindra Bolero DC turbo Spare parts, Parking Cable Front changing	No	395
114	Mahindra Bolero DC turbo Spare parts, Accelator Cablel	No	1	30	495		114	Mahindra Bolero DC turbo Spare parts, Accelator Cablel changing	No	295
115	Mahindra Bolero DC turbo Spare parts, Km Cable	No	1	30	695		115	Mahindra Bolero DC turbo Spare parts, Km Cable changing	No	295
116	Mahindra Bolero DC turbo Spare parts, Rear Axle Corn	No	1	30	95		116	Mahindra Bolero DC turbo Spare parts, Rear Axle Corn changing	No	195
117	Mahindra Bolero DC turbo Spare parts, Spring Pad	No	1	30	95		117	Mahindra Bolero DC turbo Spare parts, Spring Pad changing	No	95
118	Mahindra Bolero DC turbo Spare parts, Piston	Set	1	30	2995		118	Mahindra Bolero DC turbo Spare parts, Piston changing	Set	1995
119	Mahindra Bolero DC turbo Spare parts, Piston Ring	Set	1	30	3995		119	Mahindra Bolero DC turbo Spare parts, Piston Ring changing	Set	1995
120	Mahindra Bolero DC turbo Spare parts, Linner	Set	1	30	3995		120	Mahindra Bolero DC turbo Spare parts, Linner changing	Set	1995
121	Mahindra Bolero DC turbo Spare parts, Intake Valve	Set	1	30	595		121	Mahindra Bolero DC turbo Spare parts, Intake Valve changing	Set	895
122	Mahindra Bolero DC turbo Spare parts, Exhuast Valve	Set	1	30	695		122	Mahindra Bolero DC turbo Spare parts, Exhuast Valve changing	Set	595
123	Mahindra Bolero DC turbo Spare parts, Vale Guide	Set	1	30	395		123	Mahindra Bolero DC turbo Spare parts, Vale Guide changing	Set	495
124	Mahindra Bolero DC turbo Spare parts, Vaive Seat	Set	1	30	495		124	Mahindra Bolero DC turbo Spare parts, Vaive Seat changing	Set	695
125	Mahindra Bolero DC turbo Spare parts, Connecting Bearing	Set	1	30	1895		125	Mahindra Bolero DC turbo Spare parts, Connecting Bearing changing	Set	1295

126	Mahindra Bolero DC turbo Spare parts, Main Bearing	Set	1	30	1495		126	Mahindra Bolero DC turbo Spare parts, Main Bearing changing	Set	1595
127	Mahindra Bolero DC turbo Spare parts, Cam Shaft Bearing	Set	1	30	1295		127	Mahindra Bolero DC turbo Spare parts, Cam Shaft Bearing changing	Set	1295
128	Mahindra Bolero DC turbo Spare parts, Thrush Washer	Set	1	30	395		128	Mahindra Bolero DC turbo Spare parts, Thrush Washer changing	Set	295
129	Mahindra Bolero DC turbo Spare parts, Crank Shaft	No	1	30	2995		129	Mahindra Bolero DC turbo Spare parts, Crank Shaft changing	No	1395
130	Mahindra Bolero DC Turbo, Crank oil seal (DC Turbo)	No	1	30	995		130	Mahindra Bolero DC Turbo, Crank oil seal (DC Turbo) changing	No	895
131	Mahindra Bolero DC turbo Spare parts, Connecting Rod	No	1	30	495		131	Mahindra Bolero DC turbo Spare parts, Connecting Rod changing	No	395
132	Mahindra Bolero DC turbo Spare parts, Valve Set	Set	1	30	1395		132	Mahindra Bolero DC turbo Spare parts, Valve Set changing	Set	395
133	Mahindra Bolero DC turbo Spare parts, Grease	Kg	1	30	695		133	Mahindra Bolero DC turbo Spare parts, Grease changing	Kg	20.95
134	Mahindra Bolero DC turbo Spare parts, Dhoti	Kg	1	30	35.95		136	Mahindra Bolero DC turbo Spare parts, 4W Yok And Teeth changing	Set	1495
135	Mahindra Bolero DC turbo Spare parts, Sk Oil	Ltr	1	30	130.95		137	Mahindra Bolero DC turbo Spare parts, 2W Yok And Teeth changing	Set	595
136	Mahindra Bolero DC turbo Spare parts, Water Paper	No	1	30	50.95		138	Mahindra Bolero DC turbo Spare parts, Main Bearing Oil Seal changing	No	995
137	Mahindra Bolero DC turbo Spare parts, 4W Yok And Teeth	Set	1	30	2995		139	Mahindra Bolero DC turbo Spare parts, U-Bolt changing	No	295
138	Mahindra Bolero DC turbo Spare parts, 2W Yok And Teeth	Set	1	30	95		140	Mahindra Bolero DC turbo Spare parts, Mobil Filter changing	No	195
139	Mahindra Bolero DC turbo Spare parts, Main Bearing Oil Seal	No	1	30	995		141	Mahindra Bolero DC turbo Spare parts, Diesel Filter changing	No	295
140	Mahindra Bolero DC turbo Spare parts, U-Bolt	No	1	30	395		142	Mahindra Bolero DC turbo Spare parts, CV Joint Assembly changing	No	95
141	Mahindra Bolero DC turbo Spare parts, Mobil Filter	No	1	30	320.95		143	Mahindra Bolero DC turbo Spare parts, Dust Guard back and front changing	Set	195
142	Mahindra Bolero DC turbo Spare parts, Diesel Filter	No	1	30	295		144	Mahindra Bolero DC turbo Spare parts, Engine Oil changing	Ltr	395
143	Mahindra Bolero DC turbo Spare parts, CV Joint Assembly	No	1	30	3995		145	Mahindra Bolero DC turbo Spare parts, Coolant changing	Ltr	395

144	Mahindra Bolero DC turbo Spare parts, Dust Guard back and front	Set	1	30	295		146	Mahindra Bolero DC turbo Spare parts, Distilled Water labor charge	Ltr	50.95
145	Mahindra Bolero DC turbo Spare parts, Engine Oil	Ltr	1	30	395		147	Mahindra Bolero DC turbo Spare parts, Bonnet Cable labor charge	Set	295
146	Mahindra Bolero DC turbo Spare parts, Coolant	Ltr	1	30	395		148	Mahindra Bolero DC turbo Spare parts, Hand Brake Cable labor charge	Set	95
147	Mahindra Bolero DC turbo Spare parts, Distilled Water	Ltr	1	30	50.95		149	Mahindra Bolero DC turbo Spare parts, Door Rubber labor charge	Set	295
148	Mahindra Bolero DC turbo Spare parts, Bonnet Cable	Set	1	30	695		150	Mahindra Bolero DC Turbo Spare Parts, Door Latch Assy (DC Turbo) changing	No	195
149	Mahindra Bolero DC turbo Spare parts, Hand Brake Cable	Set	1	30	895		151	Mahindra Bolero DC turbo Spare parts, Safe Guard changing	Set	95
150	Mahindra Bolero DC turbo Spare parts, Door Rubber	Set	1	30	895		152	Mahindra Bolero DC turbo Spare parts, Fog Light labor charge	Set	695
151	Mahindra Bolero DC Turbo Spare Parts, Door Latch Assy (DC Turbo)	No	1	30	795		153	Mahindra Bolero DC turbo Spare parts, Horn changing	No	595
152	Mahindra Bolero DC turbo Spare parts, Safe Guard	Set	1	30	95		154	Mahindra Bolero DC turbo Spare parts, Pop. Shaft-Yoke & Teeth changing	No	95
153	Mahindra Bolero DC turbo Spare parts, Fog Light	Set	1	30	1595		155	Mahindra Bolero DC turbo Spare parts, Fuse changing	No	20.95
154	Mahindra Bolero DC turbo Spare parts, Horn	No	1	30	995		156	Mahindra Bolero DC turbo Spare parts, Wheel Bearing changing	No	495
155	Mahindra Bolero DC turbo Spare parts, Pop. Shaft-Yoke & Teeth	No	1	30	95		157	Mahindra Bolero DC turbo Spare parts, Sileacer pipe changing	No	95
156	Mahindra Bolero DC turbo Spare parts, Fuse	No	1	30	20.95		158	Mahindra Bolero DC turbo Spare parts, A/C filter changing	No	95
157	Mahindra Bolero DC turbo Spare parts, Wheel Bearing	No	1	30	995		159	Mahindra Bolero DC turbo Spare parts, Alternator Assy	each	795
158	Mahindra Bolero DC turbo Spare parts, Sileacer pipe	No	1	30	95		160	Mahindra Bolero DC turbo Spare parts, Alternator carbon bush changing	each	895
159	Mahindra Bolero DC turbo Spare parts, A/C filter	No	1	30	23.95		161	Mahindra Bolero DC turbo Spare parts, Alternator cut out changing	each	995
160	Mahindra Bolero DC turbo Spare parts, Alternator Assy	each	1	30	9995		164	Mahindra Bolero DC turbo Spare parts, Back bumper changing	each	595
161	Mahindra Bolero DC turbo Spare parts, Alternator carbon bush	each	1	30	1395		165	Mahindra Bolero DC turbo Spare parts, Battery cable +ive changing	Each	195

162	Mahindra Bolero DC turbo Spare parts, Alternator cut out	each	1	30	395		166	Mahindra Bolero DC turbo Spare parts, Battery cable -ive changing	Each	195
163	Mahindra Bolero DC turbo Spare parts, Anabond paste (Big)	Each	1	30	150.95		167	Mahindra Bolero DC turbo Spare parts, Bendix pinion changing	each	995
164	Mahindra Bolero DC turbo Spare parts, Anabond paste (Small)	Each	1	30	95		168	Mahindra Bolero DC turbo Spare parts, Bulb 1141 changing	each	95
165	Mahindra Bolero DC turbo Spare parts, Back bumper	each	1	30	495		169	Mahindra Bolero DC turbo Spare parts, Bulb 67 changing	each	95
166	Mahindra Bolero DC turbo Spare parts, Battery cable +ive	Each	1	30	95		170	Mahindra Bolero DC turbo Spare parts, bush stabilizer changing	per piece	195
167	Mahindra Bolero DC turbo Spare parts, Battery cable -ive	Each	1	30	95		171	Mahindra Bolero DC turbo Spare parts, Carbon bush 12 v changing	each	895
168	Mahindra Bolero DC turbo Spare parts, Bendix pinion	each	1	30	1495		172	Mahindra Bolero DC turbo Spare parts, Carbon holder changing	each	395
169	Black tape	each	1	30	30.95		173	Mahindra Bolero DC turbo Spare parts, Carbon rocker 12v changing	each	12.95
170	Mahindra Bolero DC turbo Spare parts, Bulb 1141	each	1	30	30.95		174	dash board polish, waxpol or equivalent labor charge	per piece	95
171	Mahindra Bolero DC turbo Spare parts, Bulb 67	each	1	30	30.95		175	Mahindra Bolero DC turbo Spare parts, Dynamo bearing changing	each	395
172	Mahindra Bolero DC turbo Spare parts, bush stabilizer	per piece	1	30	155.95		176	Mahindra Bolero DC turbo Spare parts, Spiadle bush changing changing	no	295
173	Mahindra Bolero DC turbo Spare parts, Carbon bush 12 v	each	1	30	95		177	Mahindra Bolero DC turbo Spare parts, Spiadle assy changing	no	395
174	Mahindra Bolero DC turbo Spare parts, Carbon holder	each	1	30	1395		178	Mahindra Bolero DC turbo Spare parts, Axle cross changing	no	395
175	Mahindra Bolero DC turbo Spare parts, Carbon rocker 12v	each	1	30	95		179	Mahindra Bolero DC turbo Spare parts, foot mat changing	set	195
176	dash board polish, waxpol or equivalent	per piece	1	30	95		180	Mahindra Bolero DC turbo Spare parts, Front bumper changing	each	395
177	Mahindra Bolero DC turbo Spare parts, Dynamo bearing	each	1	30	295		181	Mahindra Bolero DC turbo Spare parts, fuel pipe changing	per piece	395
178	Mahindra Bolero DC turbo Spare parts, Spiadle bush	no	1	30	95		183	Mahindra Bolero DC turbo Spare parts, Horn high changing	each	695
179	Mahindra Bolero DC turbo Spare parts, Spiadle assy	no	1	30	1495		184	Mahindra Bolero DC turbo Spare parts, Horn low changing	each	595
180	Mahindra Bolero DC turbo Spare parts, Axle cross	no	1	30	95		185	Mahindra Bolero DC turbo Spare parts, Horn relay changing	each	95

181	Mahindra Bolero DC turbo Spare parts, foot mat	set	1	30	2395		186	Mahindra Bolero DC turbo Spare parts, horn switch changing	each	120.95
182	Mahindra Bolero DC turbo Spare parts, Front bumper	each	1	30	1995		187	Mahindra Bolero DC turbo Spare parts, hour metre changing	each	95
183	Mahindra Bolero DC turbo Spare parts, fuel pipe	per piece	1	30	1395		188	Mahindra Bolero DC turbo Spare parts, ignition switch changing	each	95
184	Mahindra Bolero DC turbo Spare parts, grease gun	each	1	30	95		189	Mahindra Bolero DC turbo Spare parts, LT wire 5mm changing	each	95
185	Mahindra Bolero DC turbo Spare parts, Horn high	each	1	30	1995		190	Mahindra Bolero DC turbo Spare parts, LT wire 6mm changing	each	95
186	Mahindra Bolero DC turbo Spare parts, Horn low	each	1	30	1395		191	Mahindra Bolero DC turbo Spare parts, LT wire 8mm changing	each	95
187	Mahindra Bolero DC turbo Spare parts, Horn relay	each	1	30	395		192	Mahindra Bolero DC turbo Spare parts, nozzle pipe changing	per piece	95
188	Mahindra Bolero DC turbo Spare parts, horn switch	each	1	30	395		193	Mahindra Bolero DC turbo Spare parts, rain guard changing	each	95
189	Mahindra Bolero DC turbo Spare parts, hour metre	each	1	30	95		194	Mahindra Bolero DC turbo Spare parts, seat cover labor charge	set	595
190	Mahindra Bolero DC turbo Spare parts, ignition switch	each	1	30	95		195	Mahindra Bolero DC turbo Spare parts, vacuum nozzle pipe changing	each	95
191	Mahindra Bolero DC turbo Spare parts, LT wire 5mm	each	1	30	95		196	Mahindra Bolero DC turbo Spare parts, vehicle no. plate changing	per piece	95
192	Mahindra Bolero DC turbo Spare parts, LT wire 6mm	each	1	30	95		197	Mahindra Bolero DC turbo Spare parts, wheel Drum changing	per piece	395
193	Mahindra Bolero DC turbo Spare parts, LT wire 8mm	each	1	30	95		198	Mahindra Bolero DC turbo Spare parts, Wiper blade Assy changing	each	50.95
194	Mahindra Bolero DC turbo Spare parts, nozzle pipe	per piece	1	30	195		199	Mahindra Bolero DC turbo Spare parts, steering cover changing	each	95
195	Mahindra Bolero DC turbo Spare parts,rain guard	each	1	30	1595		200	Mahindra Bolero DC turbo Spare parts, Wiper motor changing	each	195
196	Mahindra Bolero DC turbo Spare parts, seat cover	set	1	30	5995		201	Mahindra Bolero DC turbo Spare parts, Bearing 6202 changing	each	195
197	Mahindra Bolero DC turbo Spare parts,vacuum nozzle pipe	each	1	30	95		202	Mahindra Bolero DC turbo Spare parts, Bearing 6302 changing	each	195
198	Mahindra Bolero DC turbo Spare parts,vehicle no. plate	per piece	1	30	495		203	Mahindra Bolero DC turbo Spare parts, Crank shaft oil seal changing	each	595
199	Mahindra Bolero DC turbo Spare parts,wheel Drum	per piece	1	30	3595		204	Mahindra Bolero DC turbo Spare parts, Drain plug changing	each	95
200	Mahindra Bolero DC turbo Spare parts,Wiper blade Assy	each	1	30	395		205	Mahindra Bolero DC turbo Spare parts, Element Assy, Fuel changing	each	295

201	Mahindra Bolero DC turbo Spare parts,steering cover	each	1	30	895		206	Mahindra Bolero DC turbo Spare parts, Element sub assy, Air changing	each	95
202	Mahindra Bolero DC turbo Spare parts, Wiper motor	each	1	30	1495		207	Mahindra Bolero DC turbo Spare parts, Engine head gasket changing	each	1995
203	Mahindra Bolero DC turbo Spare parts, Bearing 6202	each	1	30	295		208	Mahindra Bolero DC turbo Spare parts, Engine mounting changing	each	95
204	Mahindra Bolero DC turbo Spare parts,Bearing 6302	each	1	30	395		209	Mahindra Bolero DC turbo Spare parts, Engine pacing changing	each	1995
205	Mahindra Bolero DC turbo Spare parts,Crank shaft oil seal	each	1	30	0		210	Mahindra Bolero DC turbo Spare parts, Engine ring changing	each	2995
206	Mahindra Bolero DC turbo Spare parts,Drain plug	each	1	30	95		211	Mahindra Bolero DC turbo Spare parts, Fuel injection overflow pipe changing	each	195
207	Mahindra Bolero DC turbo Spare parts,Element Assy, Fuel	each	1	30	295		212	Mahindra Bolero DC turbo Spare parts, Fuel injector nozzel changing	each	195
208	Mahindra Bolero DC turbo Spare parts, Element sub assy, Air	each	1	30	395		213	Mahindra Bolero DC turbo Spare parts, Fuel injector pipe changing	each	95
209	Mahindra Bolero DC turbo Spare parts,Engine head gasket	each	1	30	2995		214	Mahindra Bolero DC turbo Spare partss, Fuel pump Assy changing	each	95
210	Mahindra Bolero DC turbo Spare parts, Engine mounting	each	1	30	895		215	Mahindra Bolero DC turbo Spare parts, Fuel pump washer changing	each	95
211	Mahindra Bolero DC turbo Spare parts, Engine pacing	each	1	30	1995		216	Mahindra Bolero DC turbo Spare parts, Fuel pump changing	No	95
212	Mahindra Bolero DC turbo Spare parts, Engine ring	each	1	30	2995		217	Mahindra Bolero DC turbo Spare parts, Hydraulic jack (Heavy Duty) changing	each	95
213	Mahindra Bolero DC turbo Spare parts, Fuel injection overflow pipe	each	1	30	295		218	Mahindra Bolero DC turbo Spare parts, Hydraulic jack (Light Duty) changing	each	95
214	Mahindra Bolero DC turbo Spare parts, Fuel injector nozzel	each	1	30	395		219	Mahindra Bolero DC turbo Spare parts, mobile changing	per ltr	395
215	Mahindra Bolero DC turbo Spare parts, Fuel injector pipe	each	1	30	495		220	Mahindra Bolero DC turbo Spare parts, Timing belt changing	each	95
216	Mahindra Bolero DC turbo Spare partss, Fuel pump Assy	each	1	30	595		221	Mahindra Bolero DC turbo Spare parts, Timing cover changing	each	95
217	Mahindra Bolero DC turbo Spare parts, Fuel pump washer	each	1	30	195		222	Mahindra Bolero DC turbo Spare parts, Timing cover gear changing	each	95
218	Mahindra Bolero DC turbo Spare parts,Fuel pump	No	1	30	2395		223	Mahindra Bolero DC turbo Spare parts, Axel lock changing	each	95

219	Mahindra Bolero DC turbo Spare parts, Hydraulic jack (Heavy Duty)	each	1	30	1895		224	Mahindra Bolero DC turbo Spare parts, Axel shaft changing	each	95
220	Mahindra Bolero DC turbo Spare parts, Hydraulic jack (Light Duty)	each	1	30	395		225	Mahindra Bolero DC turbo Spare parts, Axel shaft oil seal changing	each	95
221	Mahindra Bolero DC turbo Spare parts, mobile	per ltr	1	30	95		226	Mahindra Bolero DC turbo Spare parts, C.V joint changing	per piece	95
222	Mahindra Bolero DC turbo Spare parts, Timing belt	each	1	30	95		227	Mahindra Bolero DC turbo Spare parts, Center bearing changing	each	95
223	Mahindra Bolero DC turbo Spare parts, Timing cover	each	1	30	95		228	Mahindra Bolero DC turbo Spare parts, Clutch cylinder Assy changing	each	95
224	Mahindra Bolero DC turbo Spare parts, Timing cover gear	each	1	30	95		229	Mahindra Bolero DC turbo Spare parts, Clutch cylinder kit changing	each	95
225	Mahindra Bolero DC turbo Spare parts, Axel lock	each	1	30	95		230	Mahindra Bolero DC turbo Spare parts, Clutch kit changing	each	95
226	Mahindra Bolero DC turbo Spare parts, Axel shaft	each	1	30	195		231	Mahindra Bolero DC turbo Spare parts, Clutch kit box changing	each	95
227	Mahindra Bolero DC turbo Spare parts, Axel shaft oil seal	each	1	30	295		232	Mahindra Bolero DC turbo Spare parts, Clutch relese bearing changing	each	395
228	Mahindra Bolero DC turbo Spare parts, C.V joint	per piece	1	30	2995		233	Mahindra Bolero DC turbo Spare parts, Clutch rod changing	each	95
229	Mahindra Bolero DC turbo Spare parts, Center bearing	each	1	30	1995		234	Mahindra Bolero DC turbo Spare parts, Fly wheel changing	each	95
230	Mahindra Bolero DC turbo Spare parts, Clutch cylinder Assy	each	1	30	1795		235	Mahindra Bolero DC turbo Spare parts, Fly wheel ring changing	each	295
231	Mahindra Bolero DC turbo Spare parts, Clutch cylinder kit	each	1	30	95		236	Mahindra Bolero DC turbo Spare parts, Pilot bearing changing	each	195
232	Mahindra Bolero DC turbo Spare parts, Clutch kit	each	1	30	95		237	Mahindra Bolero DC turbo Spare parts, Tail pinion bearing (inner) changing	each	395
233	Mahindra Bolero DC turbo Spare parts, Clutch kit box	each	1	30	95		238	Mahindra Bolero DC turbo Spare parts, Tail pinion bearing (Outer) changing	each	495
234	Mahindra Bolero DC turbo Spare parts, Clutch relese bearing	each	1	30	1195		239	Mahindra Bolero DC turbo Spare parts, Wheel bearing oil seal inner (Front) changing	each	595

235	Mahindra Bolero DC turbo Spare parts,Clutch rod	each	1	30	95		240	Mahindra Bolero DC turbo Spare parts, Wheel bearing oil seal inner (Rear) changing	each	295
236	Mahindra Bolero DC turbo Spare parts,Fly wheel	each	1	30	295		241	Mahindra Bolero DC turbo Spare parts, Main leaf spring (R) changing	each	495
237	Mahindra Bolero DC turbo Spare parts, Fly wheel ring	each	1	30	295		242	Mahindra Bolero DC turbo Spare parts, Main leaf spring (F) changing	each	95
238	Mahindra Bolero DC turbo Spare parts, Pilot bearing	each	1	30	295		243	Mahindra Bolero DC turbo Spare parts, Air filter hose pipe changing	each	95
239	Mahindra Bolero DC turbo Spare parts, Tail pinion bearing (inner)	each	1	30	1295		244	Mahindra Bolero DC turbo Spare parts, Hose pipe clamp changing	each	95
240	Mahindra Bolero DC turbo Spare parts, Tail pinion bearing (Outer)	each	1	30	1495		245	Mahindra Bolero DC turbo Spare parts, Power steering box Assy changing	each	95
241	Mahindra Bolero DC turbo Spare parts, Wheel bearing oil seal inner (Front)	each	1	30	395		246	Mahindra Bolero DC turbo Spare parts, back glass changing	each	295
242	Mahindra Bolero DC turbo Spare parts, Wheel bearing oil seal inner (Rear)	each	1	30	295		247	Mahindra Bolero DC turbo Spare parts, Front Windshield glass changing	each	695
243	Mahindra Bolero DC turbo Spare parts, Main leaf spring (R)	each	1	30	1695		248	Mahindra Bolero DC turbo Spare parts, crown overhauling changing	each	2295
244	Mahindra Bolero DC turbo Spare parts, Main leaf spring (F)	each	1	30	95		250	Mahindra Bolero DC turbo Spare parts, Looking glass (R) changing	each	50.95
245	Mahindra Bolero DC turbo Spare parts, Air filter hose pipe	each	1	30	95		251	Mahindra Bolero DC turbo Spare parts, Looking glass (L) changing	each	50.95
246	Mahindra Bolero DC turbo Spare parts, Hose pipe clamp	each	1	30	95		252	Mahindra Bolero DC turbo Spare parts, Window glass changing	each	395
247	Mahindra Bolero DC turbo Spare parts, Power steering box Assy	each	1	30	1295		253	Mahindra Bolero DC turbo Spare parts, Fr. Frande arch changing	each	395
248	Mahindra Bolero DC turbo Spare parts, back glass	each	1	30	995		254	Mahindra Bolero DC turbo Spare parts, fr. handbrake cable labor charge	each	95
249	Mahindra Bolero DC turbo Spare parts, Front Windshield glass	each	1	30	4995		255	Mahindra Bolero DC turbo Spare parts, Rr handbrake cable labor charge	No	95

250	Mahindra Bolero DC turbo Spare parts,crown overhauling	each	1	30	0		256	Mahindra Bolero DC turbo spare parts, Alternate oil seal (DC TURBO) labor charge	No	195
251	Mahindra Bolero DC turbo Spare parts, denting and painting	per metre	1	30	0		257	Mahindra Bolero DC turbo spare parts, Alternator (BOSH) (mm) labor charge	No	995
252	Mahindra Bolero DC turbo Spare parts, Looking glass (R)	each	1	30	495		258	Mahindra Bolero DC Turbo Spare parts, Armature Self (Camper/DC Turbo) changing	No	995
253	Mahindra Bolero DC turbo Spare parts, Looking glass (L)	each	1	30	495		259	Mahindra Bolero DC Turbo Spare parts, Brake light bulb (DC Turbo) changing	Set	95
254	Mahindra Bolero DC turbo Spare parts, Window glass	each	1	30	995		260	Mahindra Bolero DC Turbo spare parts, Brake lining shoe (DC Turbo) changing	No	695
255	Mahindra Bolero DC turbo Spare parts, Fr. Frande arch	each	1	30	2295		261	Mahindra Bolero DC Turbo spare parts, Common meter changing	No	995
256	Mahindra Bolero DC turbo Spare parts, fr. handbrake cable	each	1	30	495		262	Mahindra Bolero DC Turbo spare parts,Control Spool-F. I Pump-Bosch. Bolero/Tata/scorpio/Dc changing	No	95
257	Mahindra Bolero DC turbo Spare parts, Rr handbrake cable	No	1	30	795		263	Mahindra Bolero DC Turbo spare parts, D Bush Front (DC Turbo) changing	No	195
258	Mahindra Bolero DC turbo spare parts, Alternate oil seal (DC TURBO)	No	1	30	395		264	Mahindra Bolero DC Turbo spare parts,Flyweight -Bosch-10.49 Pro Eicher/Scorpio/DC Turbo) changing	No	95
259	Mahindra Bolero DC turbo spare parts, Alternator (BOSH) (mm)	No	1	30	9995		265	Mahindra Bolero DC Turbo spare parts, Hose Intercooler (DC Turbo) changing	No	495
260	Mahindra Bolero DC Turbo Spare parts, Armature Self (Camper/DC Turbo)	No	1	30	2395		266	Mahindra Bolero DC Turbo spare parts,Lamp Registration plate-Bol Camper/DC Turbo/SLX changing	No	95
261	Mahindra Bolero DC Turbo Spare parts, Brake light bulb (DC Turbo)	Set	1	30	35.95		267	Mahindra Bolero DC Turbo spare parts,Lining kit-Bosch-DC Turbo-M&M changing	No	95
262	Mahindra Bolero DC Turbo spare parts, Brake lining shoe (DC Turbo)	No	1	30	695		268	Mahindra Bolero DC Turbo spare parts,Nipple Greasing	No	20.95
263	Mahindra Bolero DC Turbo spare parts, Common meter	No	1	30	695		269	Mahindra Bolero DC Turbo spare parts,Nozzle washer-F002.C71.403)- Bolero/Tata/Scorpio/DC changing	No	95

264	Mahindra Bolero DC Turbo spare parts,Control Spool-F. I Pump-Bosch. Bolero/Tata/scorpio/Dc	No	1	30	395		270	Mahindra Bolero DC Turbo spare parts, Oil separator changing	No	595
265	Mahindra Bolero DC Turbo spare parts, D Bush Front (DC Turbo)	No	1	30	195		271	Mahindra Bolero DC Turbo spare parts, Pipe Hose intercooler (DC Turbo) changing	No	395
266	Mahindra Bolero DC Turbo spare parts,Flyweight -Bosch-10.49 Pro Eicher/Scorpio/DC Turbo)	No	1	30	95		272	Mahindra Bolero DC Turbo spare parts, Power steering intake pipe housing (DC Turbo) changing	No	395
267	Mahindra Bolero DC Turbo spare parts, Hose Intercooler (DC Turbo)	No	1	30	595		273	Mahindra Bolero DC Turbo spare parts, Power steering intake pipe Metal (DC Turbo) changing	No	395
268	Mahindra Bolero DC Turbo spare parts,Lamp Registration plate-Bol Camper/DC Turbo/SLX	No	1	30	95		274	Mahindra Bolero DC Turbo spare parts, Power window switch(Main)-Scorpio/DC Turbo M&M changing	No	395
269	Mahindra Bolero DC Turbo spare parts,Lining kit-Bosch-DC Turbo-M&M	No	1	30	195		275	Mahindra Bolero DC turbo spare parts, Pump switch changing	No	295
270	Mahindra Bolero DC Turbo spare parts,Nipple Greasing	No	1	30	20.95		276	Mahindra Bolero DC Turbo spare parts,Audio tape (Sony) labor charge	No	695
271	Mahindra Bolero DC Turbo spare parts,Nozzle washer-F002.C71.403)-Bolero/Tata/Scorpio/DC	No	1	30	95		277	Mahindra Bolero DC Turbo spare parts,Electrical line check up labor charge	No	1295
272	Mahindra Bolero DC Turbo spare parts, Oil separator	No	1	30	1695		278	Mahindra Bolero DC Turbo spare parts,Caliper assybmly changing	no	395
273	Mahindra Bolero DC Turbo spare parts, Pipe Hose intercooler (DC Turbo)	No	1	30	695		279	Mahindra Bolero DC Turbo spare parts,Rear wheel sylinder changing	No	295
274	Mahindra Bolero DC Turbo spare parts, Power steering intake pipe housing (DC Turbo)	No	1	30	3895		280	Mahindra Bolero DC Turbo spare parts,Clutch cable labor charge	No	95
275	Mahindra Bolero DC Turbo spare parts, Power steering intake pipe Metal (DC Turbo)	No	1	30	3595		281	Mahindra Bolero DC Turbo spare parts,RTV changing	No	0

276	Mahindra Bolero DC Turbo spare parts, Power window switch(Main)-Scorpio/DC Turbo M&M	No	1	30	695		282	Mahindra Bolero DC Turbo spare parts,Crown tail pinion inner changing	No	895
277	Mahindra Bolero DC turbo spare parts, Pump switch	No	1	30	2995		283	Mahindra Bolero DC Turbo spare parts,Crown tail pinion bearing front changing	No	395
278	Mahindra Bolero DC Turbo spare parts,Audio tape (Sony)	No	1	30	6995		284	Mahindra Bolero DC Turbo spare parts,Crown bearing side changing	No	795
279	Mahindra Bolero DC Turbo spare parts,Electrical line check up	No	1	30	1595		285	Mahindra Bolero DC Turbo spare parts,Backgear switch changing	No	295
280	Mahindra Bolero DC Turbo spare parts,Caliper assymbly	no	1	30	9995		286	Mahindra Bolero DC Turbo spare parts,Brake light switch changing	No	195
281	Mahindra Bolero DC Turbo spare parts,Rear wheel sylinder	No	1	30	1295		287	Mahindra Bolero DC Turbo spare parts,Combination switch changing	No	295
282	Mahindra Bolero DC Turbo spare parts,Clutch cable	No	1	30	95		288	Mahindra Bolero DC Turbo spare parts,Door lock labor charge	No	195
283	Mahindra Bolero DC Turbo spare parts,RTV	No	1	30	150.95		289	Mahindra Bolero DC Turbo spare parts,Shocket rear changing	No	295
284	Mahindra Bolero DC Turbo spare parts,Crown tail pinion inner	No	1	30	7995		290	Mahindra Bolero DC Turbo spare parts,Shocket front changing	No	295
285	Mahindra Bolero DC Turbo spare parts,Crown tail pinion bearing front	No	1	30	2995		291	Mahindra Bolero DC Turbo spare parts,Indicator lamp changing	No	95
286	Mahindra Bolero DC Turbo spare parts,Crown bearing side	No	1	30	1995		292	Mahindra Bolero DC Turbo spare parts,Windshield rubber labor charge	No	295
287	Mahindra Bolero DC Turbo spare parts,Backgear switch	No	1	30	1295		293	Mahindra Bolero DC Turbo spare parts,Door pad changing	No	795
288	Mahindra Bolero DC Turbo spare parts,Brake light switch	No	1	30	395		294	Mahindra Bolero DC Turbo spare parts,Crown assembly changing	No	1595
289	Mahindra Bolero DC Turbo spare parts,Combination switch	No	1	30	1895		295	Mahindra Bolero DC Turbo spare parts,Rear axle oil seal changing	No	95
290	Mahindra Bolero DC Turbo spare parts,Door lock	No	1	30	495		296	Mahindra Bolero DC Turbo spare parts,Rear axle cone changing	No	295
291	Mahindra Bolero DC Turbo spare parts,Shocket rear	No	1	30	1595		297	Mahindra Bolero DC Turbo spare parts,Rear axle changing	No	395
292	Mahindra Bolero DC Turbo spare parts,Shocket front	No	1	30	1695		298	Mahindra Bolero DC Turbo spare parts,Wheel bolt changing	No	195

293	Mahindra Bolero DC Turbo spare parts,Indicator lamp	No	1	30	595		299	Mahindra Bolero DC Turbo spare parts,heel knot changing	No	195
294	Mahindra Bolero DC Turbo spare parts,Windshield rubber	No	1	30	1795		300	Mahindra Bolero DC Turbo spare parts,Suspension arm changing	No	95
295	Mahindra Bolero DC Turbo spare parts,Door pad	No	1	30	2995		301	Mahindra Bolero DC Turbo spare parts,Tierod end changing	No	295
296	Mahindra Bolero DC Turbo spare parts,Crown assembly	No	1	30	12995		302	Mahindra Bolero DC Turbo spare parts,Steering rack changing	No	1295
297	Mahindra Bolero DC Turbo spare parts,Rear axle oil seal	No	1	30	595		303	Mahindra Bolero DC Turbo spare parts,Thermostat valve changing	No	95
298	Mahindra Bolero DC Turbo spare parts,Rear axle cone	No	1	30	295		304	Mahindra Bolero DC Turbo spare parts,Radiator hose set metail changing	No	195
299	Mahindra Bolero DC Turbo spare parts,Rear axle	No	1	30	395		305	Mahindra Bolero DC Turbo spare parts,Radiator hose rubber changing	No	195
300	Mahindra Bolero DC Turbo spare parts,Wheel bolt	No	1	30	395		306	Mahindra Bolero DC Turbo spare parts,Radiator assembly changing	No	495
301	Mahindra Bolero DC Turbo spare parts,heel knot	No	1	30	295		307	Mahindra Bolero DC Turbo spare parts,Thermostat cap changing	No	295
302	Mahindra Bolero DC Turbo spare parts,Suspension arm	No	1	30	495		308	Mahindra Bolero DC Turbo spare parts,Engine gasket changing	No	1995
303	Mahindra Bolero DC Turbo spare parts,Tierod end	No	1	30	1095		309	Mahindra Bolero DC Turbo spare parts,Piston set changing	No	1995
304	Mahindra Bolero DC Turbo spare parts,Steering rack	No	1	30	9995		310	Mahindra Bolero DC Turbo spare parts,Number plate changing	No	95
305	Mahindra Bolero DC Turbo spare parts,Thermostat valve	No	1	30	795		311	Mahindra Bolero DC Turbo spare parts, link rod changing	No	195
306	Mahindra Bolero DC Turbo spare parts,Radiator hose set metail	No	1	30	395		312	Mahindra Bolero DC Turbo spare parts, gas kit engine changing	No	95
307	Mahindra Bolero DC Turbo spare parts,Radiator hose rubber	No	1	30	695		307	Mahindra Bolero DC Turbo spare parts,Thermostat cap changing	No	295
308	Mahindra Bolero DC Turbo spare parts,Radiator assembly	No	1	30	595		308	Mahindra Bolero DC Turbo spare parts,Engine gasket changing	No	1995
309	Mahindra Bolero DC Turbo spare parts,Thermostat cap	No	1	30	595		309	Mahindra Bolero DC Turbo spare parts,Piston set changing	No	1995
310	Mahindra Bolero DC Turbo spare parts,Engine gasket	No	1	30	3995		310	Mahindra Bolero DC Turbo spare parts,Number plate changing	No	95
311	Mahindra Bolero DC Turbo spare parts,Piston set	No	1	30	2995		311	Mahindra Bolero DC Turbo spare parts, link rod changing	No	195

312	Mahindra Bolero DC Turbo spare parts,Number plate	No	1	30	495		312	Mahindra Bolero DC Turbo spare parts, gas kit engine changing	No	95
313	Mahindra Bolero DC Turbo spare parts, link rod	No	1	30	395					
314	Mahindra Bolero DC Turbo spare parts, gas kit engine	No	1	30	1995					