

TATA Marcopolo Bus, Phuntsho Automobile Workshop					
SI No	Description of Item	Unit of Measurement	Quantity	Period of Delivery (No. of Days)	Rate
1	Tata Marco polo spare parts, oil filter	no	1	30	1095
2	Tata Marco polo bus spare parts, fuel filter	no	1	30	1295
3	Tata Marco polo bus spare parts, brake pad firt	no	1	30	95
4	Tata Marco polo bus spare parts ,Brake shoe Rr	no	1	30	1295
5	Tata Marco polo bus spare parts ,spring bush Rr	no	1	30	295
6	Tata Marco polo busspareparts,ball joint firt upper	no	1	30	95
7	Tata Marco polo bus spare parts ,ball joint firt lower	no	1	30	95
8	Tata Marco polo bus spare parts ,spring main lift	no	1	30	295
9	Tata Marco polo bus spare parts ,spring second lift	no	1	30	1595
10	Tata Marco polo bus spare parts ,spring 3rd lift	no	1	30	1295
11	Tata Marco polo bus spare parts ,4th leaf	no	1	30	1395
12	Tata Marco polo bus spare parts ,hub bearing inner	no	1	30	1995
13	Tata Marco polo bus spare parts ,hub bearing outer	no	1	30	1895
14	Tata Marco polo bus spare parts ,axle bearing	no	1	30	1795
15	Tata Marco polo bus spare parts ,check nut	no	1	30	195
16	Tata Xenon spare parts ,check nut washer	no	1	30	195
17	Tata Marco polo bus spare parts ,brake shoe hold down kit	no	1	30	95
18	Tata Marco polo bus spare parts ,headlight bulb	no	1	30	295
19	Tata Marco polo bus spare parts ,brake light bulb	no	1	30	95
20	Tata Marco polo bus spare parts ,hand brake cable fr	no	1	30	195

Labour Charge, Phuntsho Automobile Workshop			
SI NO	Description of Item	Unit of Measurement	Rate
1	Tata Marco polo spare parts, oil filter changing	no	195
2	Tata Marco polo bus spare parts, fuel filter changing	no	295
3	Tata Marco polo bus spare parts, brake pad firt changing	no	95
4	Tata Marco polo bus spare parts ,Brake shoe Rr changing	no	1395
5	Tata Marco polo bus spare parts ,spring bush Rr changing	no	295
6	Tata Marco polo busspareparts, ball joint firt upper changing	no	95
7	Tata Marco polo bus spare parts ,ball joint firt lower changing	no	95
8	Tata Marco polo bus spare parts ,spring main lift changing	no	895
9	Tata Marco polo bus spare parts ,spring second lift changing	no	295
10	Tata Marco polo bus spare parts ,spring 3rd lift changing	no	495
11	Tata Marco polo bus spare parts ,4th leaf changing	no	295
12	Tata Marco polo bus spare parts ,hub bearing inner changing	no	895
13	Tata Marco polo bus spare parts ,hub bearing outer changing	no	795
14	Tata Marco polo bus spare parts ,axle bearing changing	no	195
15	Tata Marco polo bus spare parts ,check nut changing	no	95
16	Tata Xenon spare parts ,check nut washer changing	no	95
17	Tata Marco polo bus spare parts ,brake shoe hold down kit changing	no	95
18	Tata Marco polo bus spare parts ,headlight bulb changing	no	195
19	Tata Marco polo bus spare parts ,brake light bulb changing	no	95
20	Tata Marco polo bus spare parts ,hand brake cable fr changing	no	95

21	Tata Marco polo bus spare parts ,hand brake cable Rr	no	1	30	195		21	Tata Marco polo bus spare parts ,hand brake cable Rr changing	no	95
22	Tata Marco polo bus spare parts ,weather strip	no	1	30	195		22	Tata Marco polo bus spare parts ,weather strip changing	no	95
23	Tata Marco polo bus spare parts ,alternator assy	no	1	30	6995		23	Tata Marco polo bus spare parts ,alternator assy changing	no	1295
24	Tata Marco polo bus spare parts indicator bulb	no	1	30	95		24	Tata Marco polo bus spare parts indicator bulb changing	no	95
25	Tata Marco polo bus spare parts ,clutch pad	no	1	30	6995		25	Tata Marco polo bus spare parts ,clutch pad changing	no	4995
26	Tata Marco polo bus spare parts ,release bearing	no	1	30	1995		26	Tata Marco polo bus spare parts ,release bearing changing	no	495
27	Tata Marco polo bus spare parts ,pressure plate	no	1	30	5995		27	Tata Marco polo bus spare parts ,pressure plate changing	no	3995
28	Tata Marco polo bus spare parts ,self starter assy	no	1	30	12995		28	Tata Marco polo bus spare parts ,self starter assy changing	no	1395
29	Tata Marco polo bus spare parts ,self bendix piniza	no	1	30	1995		29	Tata Marco polo bus spare parts ,self bendix piniza changing	no	995
30	Tata Marco polo bus spare parts ,self armature	no	1	30	2195		30	Tata Marco polo bus spare parts ,self armature changing	no	995
31	Tata Marco polo bus spare parts ,self bush	no	1	30	95		31	Tata Marco polo bus spare parts ,self bush changing	no	295
32	Tata Marco polo bus spare parts ,self carbon bush	no	1	30	495		32	Tata Marco polo bus spare parts ,self carbon bush changing	no	295
33	Tata Marco polo bus spare parts ,solenoid switch	no	1	30	895		33	Tata Marco polo bus spare parts ,solenoid switch changing	no	895
34	Tata Marco polo bus spare parts ,Tyre	no	1	30	11495		34	Tata Marco polo bus spare parts ,Tyre fitting and changing	no	395
35	Tata Marco polo bus spare parts ,WC assy (wheel cylinder)	no	1	30	95		35	Tata Marco polo bus spare parts ,WC assy(wheel cylinder) changing	no	95
36	Tata Marco polo bus spare parts ,TMC assy (Master cylinder)	no	1	30	3995		36	Tata Marco polo bus spare parts ,TMC assy (Master cylinder) changing	no	1295
37	Tata Marco polo bus spare parts ,CMC assy(clutch cylinder)	no	1	30	2995		37	Tata Marco polo bus spare parts ,CMC assy(clutch cylinder) changing	no	895
38	Tata Marco polo bus spare parts ,CSC (clutch cylinder lower)	no	1	30	1995		38	Tata Marco polo bus spare parts ,CSC(clutch cylinder lower) changing	no	595
39	Tata Marco polo bus spare parts ,fuse	no	1	30	20.95		39	Tata Marco polo bus spare parts ,fuse changing	no	20.95
40	Tata Marco polo bus spare parts ,battery	no	1	30	10995		40	Tata Marco polo bus spare parts ,battery changing	no	95

41	Tata Marco polo bus spare parts ,link rod	no	1	30	395		41	Tata Marco polo bus spare parts ,link rod changing	no	95
42	Tata Marco polo bus spare parts ,D-bush	no	1	30	395		42	Tata Marco polo bus spare parts ,D-bush changing	no	295
43	Tata Marco polo bus spare parts ,shocker bush	no	1	30	195		43	Tata Marco polo bus spare parts ,shocker bush changing	no	195
44	Tata Marco polo bus spare parts ,RTV	no	1	30	150.95		46	Tata Marco polo bus spare parts ,engine oil labor charge	no	395
45	Tata Marco polo bus parts ,SK oil	no	1	30	130.95		47	Tata Marco polo bus spare parts ,gear oil labor charge	no	395
46	Tata Marco polo bus spare parts ,engine oil	no	1	30	395		48	Tata Marco polo bus spare parts ,coolant labor charge	no	395
47	Tata Marco polo bus spare parts ,gear oil	no	1	30	395		49	Tata Marco polo bus spare parts ,brake oil labor charge	no	195
48	Tata Marco polo bus spare parts ,coolant	no	1	30	395		50	Tata Marco polo bus spare parts ,power steering oil labor charge	no	295
49	Tata Marco polo bus spare parts ,brake oil	no	1	30	295		52	Tata Marco polo bus spare parts ,fan belt changing	no	495
50	Tata Marco polo bus spare parts ,power steering oil	no	1	30	395		53	Tata Marco polo bus spare parts ,desk board polish labor charge	no	95
51	Tata Marco polo bus spare parts ,cloth (Doti)	no	1	30	35.95		54	Tata Marco polo bus spare parts ,wiper blade changing	no	50.95
52	Tata Marco polo bus spare parts ,fan belt	no	1	30	1295		55	Tata Marco polo bus spare parts ,spring clamp changing	no	95
53	Tata Marco polo bus spare parts ,desk board polish	no	1	30	295		57	Tata marco polo spare parts bus Dust guard back and front changing	no	395
54	Tata Marco polo bus spare parts ,wiper blade	no	1	30	395		58	Tata marco polo bus spare parts ,sileacer parts changing	no	495
55	Tata Marco polo bus spare parts ,spring clamp	no	1	30	95		59	Tata marco polo bus spare parts A/C filter changing	no	95
56	Tata Marco polo bus spare parts ,grease 1kg	no	1	30	695		60	Tata marco polo bus spare parts Alternator carbon bush changing	each	1295
57	Tata marco polo spare parts bus Dust guard back and front	no	1	30	395		61	Tata marco polo bus spare parts Alternator cut out changing	each	1395
58	Tata marco polo bus spare parts , sileacer parts	no	1	30	595		64	Tata marco polo bus spare parts, Back bumper changing	each	195
59	Tata marco polo bus spare parts A/C filter	no	1	30	95		65	Tata marco polo bus spare parts, Battery cable +ive labor charge	each	95
60	Tata marco polo bus spare parts Alternator carbon bush	each	1	30	1395		66	Tata marco polo bus spare parts, Battery cable -ive labor charge	each	95
61	Tata marco polo bus spare parts Alternator cut out	each	1	30	1395		67	Tata marco polo bus spare parts, Bendix pinion changing	each	1295

62	Tata marco polo bus spare parts Anabond paste (Big)	each	1	30	150.95		68	Black tape	each	20.95
63	Tata marco polo bus spare parts ,Anabond paste (Small)	each	1	30	95		69	Tata marco polo bus spare parts, Bulb 1141 labor charge	each	95
64	Tata marco polo bus spare parts, Back bumper	each	1	30	195		70	Tata marco polo bus spare parts, Bulb 67 labor chare	each	95
65	Tata marco polo bus spare parts,Battery cable +ive	each	1	30	195		71	Tata marco polo bus spare parts, bush stabilzer changing	per piece	295
66	Tata marco polo bus spare parts, Battery cable -ive	each	1	30	195		72	Tata marco polo bus spare parts, Carbon bush 12 v changing	no	995
67	Tata marco polo bus spare parts, Bendix pinion	each	1	30	1395		73	Tata marco polo bus spare parts, Carbon holder changing	no	995
68	Black tape	each	1	30	30.95		74	Tata marco polo bus spare parts, Carbon rocker 12v changing	no	95
69	Tata marco polo bus spare parts, Bulb 1141	each	1	30	40.95		75	Tata marco polo bus spare parts, Dynamo bearing changing	no	295
70	Tata marco polo bus spare parts, Bulb 67	each	1	30	30.95		76	Tata marco polo bus spare parts, Spiadle bush changing	no	95
71	Tata marco polo bus spare parts, bush stabilzer	per piece	1	30	195		77	Tata marco polo bus spare parts , Spiadle assy changing	no	195
72	Tata marco polo bus spare parts, Carbon bush 12 v	no	1	30	1295		78	Tata marco polo bus spare parts , Axle cross changing	no	295
73	Tata marco polo bus spare parts, Carbon holder	no	1	30	1295		79	Tata marco polo bus spare parts, foot mat changing	set	95
74	Tata marco polo bus spare parts, Carbon rocker 12v	no	1	30	95		80	Tata marco polo bus spare parts, Front bumper changing	each	595
75	Tata marco polo bus spare parts, Dynamo bearing	no	1	30	295		81	Tata marco polo bus spare parts, fuel pipe changing	per piece	95
76	Tata marco polo bus spare parts, Spiadle bush	no	1	30	95		82	Tata marco polo bus spare parts, grease gun changing	each	95
77	Tata marco polo bus spare parts , Spiadle assy	no	1	30	695		83	Tata marco polo bus spare parts, Horn high changing	each	695
78	Tata marco polo bus spare parts , Axle cross	no	1	30	295		84	Tata marco polo bus spare parts, Horn low changing	each	595
79	Tata marco polo bus spare parts, foot mat	set	1	30	3995		85	Tata marco polo bus spare parts, Horn relay changing	each	195
80	Tata marco polo bus spare parts, Front bumper	each	1	30	1295		86	Tata marco polo bus spare parts, horn switch changing	each	295
81	Tata marco polo bus spare parts, fuel pipe	per piece	1	30	295		87	Tata marco polo bus spare parts, hour metre changing	each	195
82	Tata marco polo bus spare parts, grease gun	each	1	30	95		88	Tata marco polo bus spare parts, ignition switch changing	each	95
83	Tata marco polo bus spare parts, Horn high	each	1	30	195		89	Tata marco polo bus spare parts, LT wire 5mm labor charge	each	95

84	Tata marco polo bus spare parts, Horn low	each	1	30	295		90	Tata marco polo bus spare parts, LT wire 6mm labor charge	each	95
85	Tata marco polo bus spare parts, Horn relay	each	1	30	95		91	Tata marco polo bus spare parts, LT wire 8mm labor charge	each	95
86	Tata marco polo bus spare parts, horn switch	each	1	30	95		92	Tata marco polo bus spare parts, nozzle pipe changing	per piece	195
87	Tata marco polo bus spare parts, hour metre	each	1	30	95		93	Tata marco polo bus spare parts, rain guard changing	each	295
88	Tata marco polo bus spare parts, ignition switch	each	1	30	95		94	Tata marco polo bus spare parts, seat cover changing	set	995
89	Tata marco polo bus spare parts, LT wire 5mm	each	1	30	95		95	Tata marco polo bus spare parts, vacuum nozzle pipe changing	each	195
90	Tata marco polo bus spare parts, LT wire 6mm	each	1	30	95		96	Tata marco polo bus spare parts, vehicle no. plate changing	per piece	95
91	Tata marco polo bus spare parts, LT wire 8mm	each	1	30	95		97	Tata marco polo bus spare parts, wheel Drum changing	per piece	395
92	Tata marco polo bus spare parts, nozzle pipe	per piece	1	30	195		98	Tata marco polo bus spare parts, Wiper blade Assy changing	each	50.95
93	Tata marco polo bus spare parts,rain guard	each	1	30	295		99	Tata marco polo bus spare parts, steering cover changing	each	95
94	Tata marco polo bus spare parts, seat cover	set	1	30	8995		100	Tata marco polo bus spare parts, Wiper motor changing	each	295
95	Tata marco polo bus spare parts,vacuum nozzle pipe	each	1	30	2295		101	Tata marco polo bus spare parts, Bearing 6202 changing	each	195
96	Tata marco polo bus spare parts,vehicle no. plate	per piece	1	30	495		102	Tata marco polo bus spare parts, Bearing 6302 changing	each	195
97	Tata marco polo bus spare parts,wheel Drum	per piece	1	30	195		103	Tata marco polo bus spare parts, Crank shaft oil seal changing	each	595
98	Tata marco polo bus spare parts,Wiper blade Assy	each	1	30	395		104	Tata marco polo bus spare parts, Drain plug changing	each	95
99	Tata marco polo bus spare parts,steering cover	each	1	30	795		105	Tata marco polo bus,Element Assy, Fuel changing	each	395
100	Tata marco polo bus spare parts, Wiper motor	each	1	30	395		106	Tata marco polo bus, Element sub assy, Air changing	each	395
101	Tata marco polo bus spare parts, Bearing 6202	each	1	30	395		107	Tata marco polo bus,Engine head gasket changing	each	3995
102	Tata marco polo bus spare parts,Bearing 6302	each	1	30	295		108	Tata marco polo bus, Engine mounting changing	each	295
103	Tata marco polo bus spare parts,Crank shaft oil seal	each	1	30	195		109	Tata marco polo bus, Engine pacing changing	each	2995
104	Tata marco polo bus spare parts,Drain plug	each	1	30	195		110	Tata marco polo bus, Engine ring changing	each	3995

105	Tata marco polo bus,Element Assy, Fuel	each	1	30	1295		111	Tata marco polo bus, Fuel injection overflow pipe changing	each	95
106	Tata marco polo bus, Element sub assy, Air	each	1	30	1195		112	Tata marco polo bus, Fuel injector nozzel changing	each	195
107	Tata marco polo bus,Engine head gasket	each	1	30	1995		113	Tata marco polo bus, Fuel injector pipe changing	each	295
108	Tata marco polo bus, Engine mounting	each	1	30	95		114	Tata marco polo bus, Fuel pump Assy changing	each	395
109	Tata marco polo bus, Engine pacing	each	1	30	195		115	Tata marco polo bus, Fuel pump washer changing	each	295
110	Tata marco polo bus, Engine ring	each	1	30	1295		116	Tata marco polo bus, Hydraulic jack (Heavy Duty) changing	each	95
111	Tata marco polo bus, Fuel injection overflow pipe	each	1	30	295		117	Tata marco polo bus Hydraulic jack (Light Duty) changing	each	95
112	Tata marco polo bus, Fuel injector nozzel	each	1	30	95		118	Tata marco polo bus,mobile changing	per ltr	395
113	Tata marco polo bus, Fuel injector pipe	each	1	30	95		119	Tata marco polo bus, Timing belt changing	each	95
114	Tata marco polo bus, Fuel pump Assy	each	1	30	195		120	Tata marco polo bus, Timing cover changing	each	195
115	Tata marco polo bus, Fuel pump washer	each	1	30	295		121	Tata marco polo bus, Timing cover gear changing	each	295
116	Tata marco polo bus, Hydraulic jack (Heavy Duty)	each	1	30	2295		122	Tata marco polo bus parts,Axel lock changing	each	95
117	Tata marco polo bus Hydraulic jack (Light Duty)	each	1	30	1995		123	Tata marco polo bus spare parts, Axel shaft changing	each	295
118	Tata marco polo bus,mobile	per ltr	1	30	395		124	Tata marco polo bus spare parts, Axel shaft oil seal labor charge	each	95
119	Tata marco polo bus, Timing belt	each	1	30	95		125	Tata marco polo bus spare parts, C.V joint changing	per piece	195
120	Tata marco polo bus, Timing cover	each	1	30	195		126	Tata marco polo bus spare parts, Center bearing changing	each	695
121	Tata marco polo bus, Timing cover gear	each	1	30	95		127	Tata marco polo busspare parts, Clutch cylinder Assy changing	each	695
122	Tata marco polo bus parts,Axel lock	each	1	30	95		128	Tata marco polo bus spare parts, Clutch cylinder kit changing	each	495
123	Tata marco polo bus spare parts, Axel shaft	each	1	30	95		129	Tata marco polo busspare parts, Clutch kit changing	each	395
124	Tata marco polo bus spare parts, Axel shaft oil seal	each	1	30	195		130	Tata marco polo busspare parts, Clutch kit box changing	each	295
125	Tata marco polo bus spare parts,C.V joint	per piece	1	30	95		131	Tata marco polo bus spare parts, Clutch relese bearing changing	each	495

126	Tata marco polo bus spare parts, Center bearing	each	1	30	2495		132	Tata marco polo bus spare parts, Clutch rod changing	each	295
127	Tata marco polo busspare parts, Clutch cylinder Assy	each	1	30	3995		133	Tata marco polo bus spare parts, Fly wheel changing	each	395
128	Tata marco polo bus spare parts, Clutch cylinder kit	each	1	30	2995		134	Tata marco polo bus spare parts, Fly wheel ring changing	each	295
129	Tata marco polo busspare parts, Clutch kit	each	1	30	195		135	Tata marco polo busspare parts, Pilot bearing changing	each	495
130	Tata marco polo busspare parts, Clutch kit box	each	1	30	95		136	Tata marco polo busspare parts, Tail pinion bearing (inner) changing	each	695
131	Tata marco polo bus spare parts, Clutch relese bearing	each	1	30	1995		137	Tata marco polo bus spare parts, Tail pinion bearing (Outer) changing	each	595
132	Tata marco polo bus spare parts,Clutch rod	each	1	30	295		138	Tata marco polo bus spare parts, Wheel bearing oil seal inner (Front) changing	each	395
133	Tata marco polo bus spare parts,Fly wheel	each	1	30	1295		139	Tata marco polo busspare parts, Wheel bearing oil seal inner (Rear) changing	each	295
134	Tata marco polo bus spare parts, Fly wheel ring	each	1	30	1195		140	Tata marco polo bus spare parts, Main leaf spring (R) changing	each	995
135	Tata marco polo busspare parts, Pilot bearing	each	1	30	495		141	Tata marco polo bus spare parts, Main leaf spring (F) changing	each	895
136	Tata marco polo busspare parts, Tail pinion bearing (inner)	each	1	30	1295		142	Tata marco polo bus spare parts, Air filter hose pipe changing	each	295
137	Tata marco polo bus spare parts, Tail pinion bearing (Outer)	each	1	30	1195		143	Tata marco polo bus spare parts, Hose pipe clamp changing	each	95
138	Tata marco polo bus spare parts, Wheel bearing oil seal inner (Front)	each	1	30	695		144	Tata marco polo busspare parts, Power steering box Assy changing	each	1295
139	Tata marco polo busspare parts, Wheel bearing oil seal inner (Rear)	each	1	30	495		145	Tata marco polo bus spare parts, back glass changing	each	1295
140	Tata marco polo bus spare parts, Main leaf spring (R)	each	1	30	1995		146	Tata marco polo bus spare parts, Front Windshield glass changing	each	1995
141	Tata marco polo bus spare parts, Main leaf spring (F)	each	1	30	1895		147	Tata marco polo bus spare parts, crown overhauling changing	each	2995
142	Tata marco polo bus spare parts, Air filter hose pipe	each	1	30	295		149	Tata marco polo bus spare parts, Looking glass (R) changing	each	95
143	Tata marco polo bus spare parts, Hose pipe clamp	each	1	30	95		150	Tata marco polo bus spare parts, Looking glass (L) changing	each	95

144	Tata marco polo busspare parts, Power steering box Assy	each	1	30	1495		151	Tata marco polo bus spare parts, Window glass changing	each	395
145	Tata marco polo bus spare parts, back glass	each	1	30	895					
146	Tata marco polo bus spare parts, Front Windshield glass	each	1	30	6995					
149	Tata marco polo bus spare parts, Looking glass (R)	each	1	30	795					
150	Tata marco polo bus spare parts, Looking glass (L)	each	1	30	895					
151	Tata marco polo bus spare parts, Window glass	each	1	30	5995					